





FOREWORD

Congratulations on being an owner of a versatile **KIOTI CK20** tractor. This tractor has been designed with the finest materials and under rigid quality control standards set forth by the **DAEDONG** engineering department. Knowledge of tractor operation is essential for many years of dependable service and reliability. This manual is given to help you familiarize yourself with the **CK20** tractor and to give you helpful information about tractor safety, operation and maintenance. It is the policy of **KIOTI** to provide each **KIOTI** tractor owner with a detailed owner's manual to help you answer many questions. If the information you are seeking is not found in this manual, your **KIOTI** tractor dealer will be happy to help you.

Please feel free to contact **DAEDONG IND.CO.,LTD.**

Throughout this manual, you will see text in italics, preceded by the words **DANGER**, **WARNING**, **CAUTION** or **IMPORTANT**.

Such text has the following significance.























Signs		Description
	DANGER	This mark indicates hazardous situation which, if not observed, may result in death or fatal injury. This mark should be indicated for most dangerous situations only.
	WARNING	This mark indicates potentially hazardous situation which, if not observed, may result in death or moderate injury.
	CAUTION	This mark indicates potentially hazardous situation which, if not observed, may result in minor or moderate injury. And this mark can be used as a warning against unsafe activities.
	IMPORTANT	This mark indicates emphasis on notable characteristics in working procedures or information on working procedures and technology for convenient use.

ABBREVIATION LIST

Abbreviations	Definitions
4WD	Four Wheel Drive
API	American Petroleum Institute
ASAE	American Society of Agricultural Engineers, USA
ASTM	American Society of Testing and Materials, USA
fpm	Feet Per Minute
Hi-Lo	High Speed-Low Speed
HST	Hydrostatic Transmission
m/s	Meters Per Second
P.T.O	Power Take OFF
RH/LH	Right-hand and Left-hand sides are determined by facing in the direction of forward travel
ROPS	Roll-Over Protective Structures
m ⁻¹ (rpm)	Revolutions Per Minute
S ⁻¹ (r/s)	Revolutions Per Second
SAE	Society of Automotive Engineers, USA
SMV	Slow Moving Vehicle

UNIVERSAL SYMBOLS

Various universal symbols have been used on the instruments and controls of your **KIOTI** tractor. Below is a list of the universal symbols and their meanings.

	Safety Alert Symbol		Hazard Warning Lights
	Fuel-Level		Master Lighting Switch
	Engine Coolant-Temperature		Position Lamps
	Parking Brake		Headlight-Low Beam
	Battery Charging Condition		Headlight-High Beam
	Engine Oil-Pressure		Audible Warning Device
	Turn Signal		Four-Wheel Drive-ON
	Power Take-OFF Clutch Control-OFF Position		Four-Wheel Drive-OFF
	Power Take-OFF Clutch Control-ON Position		Fast
	Differential Lock		Slow
	Position Control-Raised Position		
	Position Control-Lowered Position		

CONTENTS

1. SAFETY PRECAUTIONS	
2. SERVICING	
3. SPECIFICATIONS	
4. INSTRUMENT PANEL AND CONTROLS	
5. PRE-OPERATION CHECK	
6. OPERATING THE ENGINE	
7. OPERATING THE TRACTOR	
8. THREE-POINT HITCH & DRAWBAR	
9. HYDRAULIC UNIT	
10. TIRES, WHEELS AND BALLAST	
11. MAINTENANCE	
12. PERIODIC SERVICE	
13. STORAGE	
14. TROUBLESHOOTING	
15. OPTIONS	
16. INDEX.....	


1

SAFETY PRECAUTIONS


**BEFORE OPERATING THE TRACTOR
OPERATING THE TRACTOR
DRIVING THE TRACTOR
PARKING THE TRACTOR
OPERATING THE P.T.O
USING 3-POINT HITCH
SERVICING THE TRACTOR
TRACTOR SAFETY LABELS**

BEFORE OPERATING THE TRACTOR


A careful operator is the best operator. Most accidents can be avoided by observing certain precautions. To help prevent accidents, read and take these safety precautions and pay attention to the job at hand. If you can prevent an accident in advance, your time will have been spent well.




1. It is recommended that you read and understand this entire manual before operation of your new tractor. Failure to do so could result in accidents or injury.
2. Only persons who are properly trained should be allowed to operate the tractor.
3. Read and follow all warning labels and decals affixed on the tractor.
4. Replace any missing or damaged decals as soon as practical. A list on decals is shown on page 1-14.
5. Keep safety decals clean from dirt and debris.




6. When getting on and off the tractor, handholds and step plates should always be used. This will help to prevent accidental slips, trips and falls.
7. Be sure to scrape off mud or soil from your shoes before mounting the tractor.
8. Watch where you are going at all times so that you are able to avoid obstacles that can cause injury or damage to your tractor.
9. When starting the tractor make sure your path is clear of people to avoid accidents caused by sudden movements.
10. Before making reverse movements with your tractor you should always check to see that the path is clear.




11. Never operate this tractor or any other agricultural equipment while under the influence of alcohol, drugs, or while fatigued.
12. While working in cooperation with other tractors always communicate your intentions.
13. Do not start your tractor by shorting across the starter.



14. Never start the engine while standing on the ground.
15. Only the operator should ride on the tractor unless a passenger seat is installed. Keep bystanders away from the tractor while in operation.



16. All persons using the tractor should have knowledge of its proper operation, and should read this manual carefully.
17. Never get off the tractor without shutting off the tractor, setting the parking brake, and lowering the implement to the ground.
18. No alterations should be made to your **KIOTI** tractor without first consulting you **KIOTI** dealer.



19. Before starting your tractor you should disengage the clutch, and insure that all shift levers are in the neutral position.


20. For your safety **ROPS** with a seat belt is recommended for most applications.

NOTE

- Always use seat belt when the tractor is equipped with a **ROPS**. Never use the seat belt when tractor is not equipped with a **ROPS**. (**ROPS**: Roll-Over Protective Structures)




A **ROPS** should never be modified by welding, grinding, or cutting, as this can weaken the **ROPS** structure. If any components of the **ROPS** unit is damaged it must be replaced.

If the **ROPS** unit is removed or loosened for any reason, the parts should be fitted back to their originals position and all bolts should be properly torqued.




(1) Tread

21. Extra caution should be taken when driving tractors with narrow tread widths. For added stability you should adjust you rear wheel tread width, see page 12-20.


OPERATING THE TRACTOR

1. Avoid accidental contact with gear shift levers while the engine is running. Unexpected tractor movements can result in bodily injury.
2. Do not park your tractor on a steep incline, and remember to shut off the engine and P.T.O before dismounting the tractor.
3. Do not operate your tractor in an enclosed building without the proper ventilation. Exhaust fumes can cause serious injury or death.




196O111A

(1) Drawbar



196O112A





196O113A

4. Make sure that all pressured lines are tight before starting the tractor.
5. Pull only from the drawbar. Never hitch anything to the axle housing or any other point except the drawbar. Such arrangements only increase the risk of serious personal injury or death.

6. If the front of the tractor tends to rise up when heavy implements are attached to the three point hitch, from weights should be installed on the tractor. Do not operate the tractor with a light front end.

7. Do not leave equipment in the raised position when the vehicle is stopped or unattended.
8. When using implements or attachments with your tractor you should first read their respective owner's manual. You should always keep their safe operation procedures in mind.
9. You should be familiar with your equipment and its limitations.
10. Always use the proper ballast weight on your tractor when using rear implements.


11. Driving forward out of a ditch or steep inclines can cause the tractor to tip over backwards. To avoid this you should back out of these positions. Four wheel drive tractors can give you a false sense of security in the tractors ability to maneuver out of these positions, so extra caution should be taken.
12. You should watch for and avoid obstacles at row ends, near trees, and around other obstructions.



13. If abused or used incorrectly your tractor can become dangerous to you and bystanders. Overloading your tractor or using unsafe equipment can also be dangerous and should be avoided. Refer to the "Specifications of Implement Limitation", which outlines the maximum load for safe tractor operation.


14. Never try to get on or off a moving tractor.
15. When working in groups, always let the others know what you are going to do before you do it.
16. Never "freewheel". Disengaging the clutch or shifting into neutral while descending a slope could lead to a loss of control.
17. Do not operate near ditches, holes, embankments, or other terrain features which may collapse under the tractor's weight. The risk of tractor upset is even higher when the ground is loose or wet.

DRIVING THE TRACTOR




(1) Brake Pedal Lock (2) Brake Pedal (L)
(3) Brake Pedal (R)

1. Lock the brake pedals together when traveling at road speeds. Brake both wheels simultaneously when making an emergency stop. Uneven braking at road speeds could cause the tractor to tip over.




(1) Brake Pedal Lock (2) Brake Pedal (L)
(3) Brake Pedal (R)



2. Always slow the tractor down before turning. Turning at high speed may tip the tractor over.


PARKING THE TRACTOR



(1) SMV Emblem


3. Make sure that the Slow Moving Vehicle (SMV) sign is clean and visible. Use hazard lights as required.

4. Observe all local traffic and safety regulations.
5. Turn the headlights on. Dim them when meeting another vehicle.
6. Drive at speeds that allow you to maintain control at all times.
7. Do not apply the differential lock while traveling at road speeds. The tractor may run out of control.
8. Avoid sudden movements of the steering wheel as it can cause a loss of control of the tractor. This risk is especially great when traveling at road speeds.
9. Do not operate an implement while the tractor is on the road. Lock the three pint hitch in the raised position.
10. When towing other equipment, use a safety chain and place an SMV emblem on it as well.




1. Disengage the P.T.O, lower all implements, place all control levers in the neutral position, set the parking brake, stop the engine, and remove the key.

OPERATING THE P.T.O




(1) P.T.O Shaft Cap (2) P.T.O Shaft Cover

1. Make sure the tractor is completely stopped, and all moving components have completely stopped, before connecting, disconnecting, adjusting, cleaning, or servicing any P.T.O driven equipment.
2. Keep the P.T.O shaft cover in place at all times. Replace the P.T.O shaft cap when the shaft is not in use.



3. Before installing or using P.T.O driven equipment, read the manufacturer's manual and review the safety labels attached to the equipment.
4. When operating stationary P.T.O driven equipment, always apply the tractor parking brake and place chocks behind and in front of the rear wheels. Stay clear of all rotating parts.


USING 3-POINT HITCH



(1) 3-point hitch lowering speed knob
 (A) "FAST" (C) "LOCK"
 (B) "SLOW"

1. Use the 3-point hitch only with equipment designed for 3-point hitch usage.
2. When using a 3-point hitch mounted implement, be sure to install the proper counterbalance weight on the front of the tractor.
3. When transporting on the road, set the implement lowering control in the "LOCK" position to hold the implement in the raised position.

SERVICING THE TRACTOR



196O125A


In order to service your tractor you must park it on a flat level surface, set the parking brake, place the gear shift level in neutral and stop the engine.

1. Allow the tractor time to cool off before servicing any part that may have become hot while the tractor was running.
2. You must always stop the engine before refueling the tractor. Avoid overfilling the tractor or spilling the fuel.
3. Do not smoke while working around the battery or when refueling your tractor. Keep all sparks and flames away for the battery and fuel tank. The battery presents an explosive hazard because it gives off hydrogen and oxygen... especially when recharging.




196O126A

4. Before jump starting a dead battery, read and follow all of the instructions.
5. Keep a first aid kit and fire extinguisher handy at all times.




196O127A


6. Do not remove the radiator cap while the coolant is hot. When cool, slowly rotate the cap to the first stop and allow sufficient time for excess pressure to escape. After all the pressure is released remove the cap completely. If your tractor is equipped with a coolant recovery tank, add coolant there instead of to the radiator.



7. When working with your tractors electrical components you must first disconnect the battery cables.
8. To ensure that there are no accidents from sparks you must first disconnect the negative battery cable.




9. Tire mounting should be done by qualified professionals, with the proper equipment.
10. Maintaining correct tire pressure is important for the life of your tires. You should not inflate the tires above the recommended pressure specified in the owner's manual.



- (1) Cardboard
(2) Hydraulic Line
(3) Magnifying Glass

11. Securely support the tractor when changing wheels or the wheel tread width.
12. Make sure that wheel bolts have been tightened to the specified torque.
13. Escaping hydraulic fluid under pressure has sufficient force to penetrate skin, causing serious personal injury. Before disconnecting hydraulic lines, be sure to release all residual pressure. Before applying pressure to the hydraulic system, make sure that all connections are tight and that all line, pipes, and hoses are free of damage.




14. Fluid escaping from pinholes may be invisible. Do not use hands to search for suspected leaks;


Use a piece of cardboard or wood, instead. Use of safety goggles or other eye protection is also highly recommended. If injured by escaping fluid, see a medical doctor at once. This fluid can produce gangrene or severe allergic reaction.

TRACTOR SAFETY LABELS


USA



EU




(1) Part No. : T2350-54122



(3) Part No. : T4625-52361




(5) Part No. : T2325-51962




(2) Part No. : T4625-52351



(4) Part No. : T2325-50743




(6) Part No. : T2445-50724



(7) Part No. : T2615-53561

⚠ WARNING




Do not remove the radiator cap when the engine is running or while the engine is hot. If the radiator cap is removed, hot vapors or liquid may be violently released causing burns. Allow a sufficient amount of time for the engine to cool before removing the radiator cap.


T2615-53561

(9) Part No. : T2615-54112

⚠ WARNING



- Avoid flames and sparks.
- STOP engine while refueling.



ONLY use diesel.

T2615-54112

(8) Part No. : T2350-54141

⚠ WARNING

- This lever is for the purpose of operating the remote control valve.
- Do NOT grasp the joystick lever when mounting the tractor. Use only the hand holds provided.
- When the joystick lever is broken or damaged, it can cause serious trouble.


T2350-54141

2 **SERVICING OF TRACTOR**


SERVICING THE TRACTOR

SERVICING


KIOTI TRACTOR



(1) Statutory Plate
(2) Identification No.(EU)



(1) Engine Serial Number



(1) Transmission Serial Number

Your dealer is interested in your new tractor and has the desire to help you get the most value from it. After reading this manual thoroughly, you will find that you can do some of the regular maintenance yourself. However, when in need of parts or major service, be sure to see your **KIOTI** dealer. For service, contact the **KIOTI** dealership from which you purchased your tractor or your local authorized **KIOTI** dealer.

When in need of parts, be prepared to give your dealer both the tractor and engine serial numbers.

The tractor serial number is located on the transmission housing on the left side of the tractor. The engine serial number is located on the right side of the engine crankcase. Locate the serial numbers now and record them in the space provided.

Before using implements not sold by **KIOTI DISTRIBUTOR**, contact your nearest dealer, regarding safety in its application.

Identification No.

Engine Serial No.

Transmission Serial No.

Date of Purchase

(To be filled in by purchaser)

3 SPECIFICATIONS

SPECIFICATIONS
IMPLEMENT LIMITATIONS

SPECIFICATIONS

Model		CK20	
		MECHANICAL	HST
Engine	Model	3C093	
	Type	Liquid-cooled, 3-cylinder diesel	
	Engine gross HP (kW)	21 (15.7)	
	P.T.O(Factory observed) HP (kW)/rpm	16.5 (12.3)/2800	15.5 (11.6)/2800
	Displacement cc (cu.in)	927 (56.6)	
	Rated revolution r.p.m min-1	2,800	
	Fuel tank capacity ℓ (gal.)	20 (5.28)	
Drive train	Clutch	Dry type single stage	
	Transmission	synchro/constant	Hydrostatic
	Speeds	6F 2R	INF.2
	Differential lock	Standard	
	Brake	Wet disc type	
	P.T.O	Transmission	Live continuous
	Rear (rpm)	1 speed (540 rpm at 2,646 engine rpm)	
	Mid (rpm)	1 speed (2,000 rpm at 2,706 engine rpm)	
Hydraulic system	Pump capacity (Max. flow rate) ℓ/min (gpm)	29 (7.66)	
	3-point hitch	Cat.I	
	Maximum lifting capacity (24in. aft of hitch) kg (lbs)	503 (1,109)	
	Hydraulic lift control system	Position control	
	Steering	Hydrostatic	

Model		CK20		
		MECHANICAL	HST	
Standard tire size	Front (AG, TURF, INDUSTRIAL)	6 - 12 (23 x 8.50 - 12, 23 x 8.50 - 12)		
	Rear (AG, TURF, INDUSTRIAL)	9.5 - 16 (33 x 12.5 x 16.5, 12 - 16.5)		
Traveling speeds	Forward (At rated engine rpm) km/h (mph)	1.10 ~ 16.24 (0.68 ~ 10.09)	0 ~ 14.97 (0 ~ 9.30)	
	Reverse (At rated engine rpm) km/h (mph)	1.36 ~ 6.31 (0.85 ~ 3.92)	0 ~ 9.37 (0 ~ 5.82)	
Dimensions	Overall length (with 3p) mm (in.)	2,684 (105.7)		
	Overall width (minimum tread) mm (in.)	1,121 (44.1)		
	Overall height (Top of ROPS) mm (in.)	1,970 (77.5)		
	Wheel base mm (in.)	1,470 (57.9)		
	Min. ground clearance mm (in.)	310 (12.2)		
	Tread	Front mm (in.)	910 (35.8)	
		Rear mm (in.)	890 - 935 (35.0 - 36.8)	
	Min. turning radius (with brake) m (Ft.)	2.3 (7.5)		
Weight (with rops) kg (lbs.)	890 (1,962)	904 (1,993)		

NOTE: The specifications are subject to change for the purpose of improvement without any notice.

IMPLEMENT LIMITATIONS

The **KIOTI** tractor has been thoroughly tested for proper performance with implements sold or approved by **KIOTI**. Use with implements which are not sold or approved by **KIOTI** and which exceed the maximum specifications listed below, or which are otherwise unfit for use with the **KIOTI** tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

Model \ Item	Tread (max. width)		Lifting Capacity max. loading weight (24 in. aft of hitch)
	Front	Rear	
CK20	910 mm (35.8 in.)	940 mm (37 in.)	503 kg (1,109 lbs)
CK20H			


Model \ Item	Actual figures		Trailer loading weight W_3 Max. capacity
	Implement weight W_1 and / or size	Max. Drawbar Load W_2	
CK20	As in the following list (shown on the next page)	250 kg (551 lbs.)	812 kg (1,792 lbs.)
CK20H			

Lifting Capacity max. loading weight The max. allowable load which can be put on the 24 in. aft of hitch : W_0

Implement weight The implement's weight which can be put on the lower link : W_1

Max. drawbar load W_2

Trailer loading weight The max. loading weight for trailer (without trailer's weight) : W_3




NOTE: Implement size may vary depending on soil operating conditions.

Implement	Remarks	CK20	CK20H	Remarks
Loader	Max. Bucket width mm(in)	1219.2(48),1371.6(54)		Operating Capa.300kg(660lbs) and below
Backhoe with sub frame	Max. Diging depth mm(ft.in)	1955.8(6.5) and below		Do not use 3 point hitch backhoe
Mid Mower	Max. Cutting width mm(in)	1524(60) and below		
Tiller	Max. Cutting width mm(in)	1193.8(47) and below		
Bot blade	Max. Cutting width mm(in)	1219.2(48) and below		
Rear Blade	Max. Cutting width mm(in)	1524(60) and below		
Rotary cutter	Max. Cutting width mm(in)	1320.8(52),1524(60)		
Belt fuard	Max. Cutting width mm(in)	1320.8(52),1524(60)		
Chain guard	Max. Cutting width mm(in)	1320.8(52),1524(60)		
Bale transport	Max. Width mm(in)	1219.2(48) and below		
Core Aerator	Max. Width mm(in)	1219.2(48),1524(60)		

4 INSTRUMENT PANEL AND CONTROLS


**INSTRUMENT PANEL, SWITCHES AND HAND CONTROLS
FOOT AND HAND CONTROLS**

INSTRUMENT PANEL, SWITCHES AND HAND CONTROLS



- (1) *Left Turn Indicator*
- (2) *Cooling Water Temp. Gauge*
- (3) *Turn Signal Switch & Light Switch*
- (4) *Hazard Lamp Switch*
- (5) *Engine Revolution Gauge*
- (6) *Right Turn Indicator*
- (7) *Fuel Gauge*
- (8) *Key Switch*
- (9) *Engine Stop Knob*
- (10) *Horn Switch(only EU)*


FOOT AND HAND CONTROLS



- (1) Shuttle Shift Lever
- (2) Clutch Pedal
- (3) Hi-Lo Shift Lever
- (4) Parking Brake Lock Lever
- (5) Hand Throttle
- (6) Brake Pedal (L)
- (7) Brake Pedal (R)
- (8) Foot Throttle (M)
- (9) Joystick Lever
- (10) Double Acting Lever (A, B)
- (11) Hydraulic Control Lever
- (12) Mid P.T.O Shaft Lever
- (13) Rear P.T.O Shaft Lever
- (14) Handbrake(only EU)

NOTE : The rearview mirror and the seat are only for the EU spec.

CK20H



- (1) Forward/Back Ward Shuttle Pedal
- (2) Clutch Pedal
- (3) Hi-Lo Shift Lever
- (4) Parking Brake Lock Lever
- (5) Hand Throttle
- (6) Brake Pedal (L)
- (7) Brake Pedal (R)
- (8) Joystick Lever
- (9) Double Acting Lever (A, B)
- (10) Speed Set Lever
- (11) Hydraulic Control Lever
- (12) Mid P.T.O Shaft Lever
- (13) Rear P.T.O Shaft Lever

NOTE : The rearview mirror and the seat are only for the EU spec.

5 PRE-OPERATION

DAILY CHECK

DAILY CHECK

It is a good practice to know the condition of your tractor before you start it. You should do routine check before each use.


CAUTION

To avoid personal injury:

- Be sure to check and service the tractor on a level surface with the engine shut off and the parking brake “ENGAGED”.
- Refuel (See “DAILY CHECK” in periodic service section.)
- Care of danger, warning and caution labels (See “DANGER, WARNING AND CAUTION LABELS” in safe operation section.)

CHECK ITEM

- Do a walk around inspection.
- Check the engine oil level
- Check the transmission oil level
- Check the coolant level
- Clean the grill and radiator screen.
- Check the air cleaner and evacuator valve.
- Check the brake pedal
- Check all dash gauges and indicators
- Check head lights, tail lights, and all working lights.
- Check accessible wiring harness for any damage.
- Check the seat belt and **ROPS** for damage.
- Refuel (See “daily check” in the periodic service section)
- Check all danger and warning labels.



6 OPERATING THE ENGINE

**STARTING THE ENGINE
STOPPING THE ENGINE
WARMING UP
JUMP STARTING**

STARTING THE ENGINE


⚠ CAUTION

To avoid personal injury:

- You must read and understand the warning and caution labels on your tractor.
- Proper ventilation is required when operation your tractor inside a building or enclosed area. Remember that exhaust fumes can be deadly.
- Never start your tractors engine while standing on the ground. This can prevent unexpected accident from happening.

⊕ IMPORTANT

- Using starting fluid or ether to start your tractor will cause damage and void your tractors warranty.
- A good way to start your tractors engine after a long storage period you should pull the stop knob and turn the key over. This will allow time for oil to reach every part of the tractors engine before starting.
- To avoid damage to the starter and battery you should never continuously start your tractor for more than 30 second at a time.




- (1) Parking Brake Lever
 (A) Interlock the Brake Pedals
 (B) "DEPRESS"
 (C) "PULL"

MAKE SURE THE PARKING BRAKE IS SET

1. To set the parking brake;
 - 1) interlock the brake pedals
 - 2) Depress the brake pedals
 - 3) Latch the brake pedals with the parking brake lever.
2. To release the parking brake you should press the brake pedals again.

⊕ IMPORTANT

- Make sure that the parking brake pedals are fully depressed before pulling the parking brake lever up.



- (1) P.T.O Clutch Lever
- (2) Speed Control Pedal
- (3) Range Gear Shift Lever (Hi-Lo)

- "ON"
- "OFF"
- "HI"
- (N) "NEUTRAL POSITION"
- "Lo"

PLACE THE P.T.O CLUTCH LEVER IN "OFF" POSITION.


PLACE THE SPEED CONTROL PEDAL IN "NEUTRAL" POSITION.

PLACE THE RANGE GEAR SHIFT LEVER (HI-LO) IN "NEUTRAL" POSITION.

NOTE

- The speed control pedal automatically return to neutral when the operator's foot is released from the pedal.

MOVE THE HYDRAULIC CONTROL LEVER FORWARD.




- (1) Hydraulic Control Lever
- (A) "DOWN"



To lower implement, move the hydraulic control lever forward.

Hydraulic control lever is automatically returned to neutral position when implement is down at lowest position.


SET THE THROTTLE LEVER TO ABOUT HALF WAY









(1) Hand Throttle Lever

-  "INCREASE"
-  "DECREASE"


INSERT THE KEY INTO THE KEY SWITCH AND TURN IT "ON".



-  Off
-  Accessory
-  Key On
-  Pre-Heat
-  Start(USA)
-  Start(EU)

CHECK EASY CHECKER LAMPS:

1. When the key is turned "ON", lamps (3), (4) should come on. If trouble should occur at any location while the engine is running, the warning lamp corresponding to that location comes on.
2. Glow plug indicator (5) also comes on when the key is turned "ON" to pre-heat the engine and goes off automatically when preheat is completed.



- (1) Easy Checker
- (2) Key Switch
- (3) Engine Oil Pressure
- (4) Electrical Charge
- (5) Glow Plug Indicator
- (6) Parking Brake
- (7) High Light

3. The parking brake warning lamp (6) comes on while parking brake is applied and goes off when it is released.

⊕ IMPORTANT

- **Daily checks with the Easy Check only, are not sufficient. Never fail to conduct daily checks carefully by referring to Daily Check. (See "DAILY CHECK" in Periodic Service Section)**

TURN THE KEY TO "PREHEAT" POSITION AND HOLD IT FOR ABOUT 9 SECONDS.

NOTE

- Glow plug indicator (5) comes on while engine is being preheated.

TURN THE KEY TO "START" POSITION AND RELEASE WHEN THE ENGINE STARTS.


⊕ IMPORTANT

- **The engine will not start unless the range gear shift lever (Hi-Lo) and the P.T.O clutch lever are in the "OFF" position.**

CHECK TO SEE THAT ALL THE LAMPS ON THE EASY CHECKER ARE "OFF".

If the lamp is still on, immediately stop the engine and determine the cause.

STOPPING THE ENGINE



1. You must first slow the engine to the idle position before turning the engine off.
2. Remove the key.

WARMING UP

⚠ CAUTION

- During warm up of the engine be sure that the parking brake is set.

After starting your tractors engine allow five minute warm up before applying any load to the tractor. This will allow time for oil to reach every part of the engine. If a load is applied to the tractor before it has time to warm up then serious damage can occur like, premature wear, breakage, or seizure.

WARM-UP AND TRANSMISSION OIL IN THE LOW TEMPERATURE RANGE

- Hydraulic oil serves as transmission fluid. In cold weather, the oil may be cold with increased viscosity. This can cause delayed oil circulation or abnormally low hydraulic pressure for some time after engine start-up. This in turn can result in trouble in the hydraulic system. To prevent the above, observe the following instructions:
- Warm up the engine at about 50 % of rated rpm according to the table below:

Ambient temperature	Warm-up time requirement
Above 0 °C (32 °F)	At least 5 minutes
0 ~ -10 °C (32 ~ 14 °F)	5 ~ 10 minutes
-10 ~ -20 °C (14 ~ -4 °F)	10 ~ 15 minutes
Below -20 °C (-4 °F)	More than 15 minutes

⊕ IMPORTANT

- Do not operate the tractor under full load condition until it is sufficiently warmed up.

JUMP STARTING


⚠ CAUTION

To avoid personal injury:

- Keep all flames, sparks, and cigarettes away from the battery.
- If the tractor's battery is frozen, do not jump start the engine.

When jump starting the engine, follow the instructions below to safely start the engine.

1. Use a battery of the same voltage as the disabled tractor to jump start the tractor. Make sure the battery is within a safe distance to the tractor so that the jumper cables can reach.
2. Engage the parking brake of the tractor and shut the tractor off.
3. Put on safety goggles and rubber gloves.
4. Make sure that the battery vent caps are securely in place.
5. Cover the vent hole with damp rags, and do not allow the rags to touch the battery terminals.
6. Attach the red clamp to the positive terminal of the dead battery, and attach the other end to the positive cable of the helper battery.
7. Clamp the black cable to the negative terminal of the dead battery, and attach the other end to the negative cable of the engine hook.
8. If the helper battery is in a vehicle, start the vehicle's engine and let it run for a few moments. Then start the disabled tractor.
9. Disconnect the battery cables in the exact opposite order as they were attached.
10. Remove the damp rags and reinstall the vent caps.



Connect cables in numerical order. Disconnect in reverse order after use.

- (1) Dead Battery
 (2) Lay a Damp Rag Over the Vent Caps
 (3) Jumper Cables (4) Helper Battery

⊕ IMPORTANT

- This tractor has a 12 volt negative ground starting system.
- Use only the same voltage for jump starting the tractor.
- The use of a higher voltage system for jump starting can cause severe damage to the tractor's electrical system.
- Use only a matching voltage source when "Jump Starting" a dead battery.

7

OPERATING THE TRACTOR

OPERATING NEW TRACTOR
OPERATING FOLDABLE ROPS
STARTING
STOPPING
CHECK DURING DRIVING
PARKING
OPERATING TECHNIQUES
P.T.O OPERATION

OPERATING NEW TRACTOR

How a new tractor is handled and maintained determines the life of the tractor.

A new tractor just off the factory production line has been, of course, tested, but the various parts are not accustomed to each other, so care should be taken to operate the tractor for the first 50 hours at a slower speed and avoid excessive work or operation until the various parts become “broken-in.” The manner in which the tractor is handled during the “breaking-in.” period greatly affects the life of your tractor. Therefore, to obtain the maximum performance and the longest life of the tractor, it is very important to properly break-in your tractor.

In handling a new tractor, the following precautions should be observed.

- You should not operate your tractor at full speed for the first fifty hours of use.
- Do not start your tractor abruptly or apply the brakes suddenly.
- In cold climates, allow your tractor plenty of time to warm up.
- Do not run the engine at speeds faster than necessary.
- Use due caution when operating your tractor on rough roads or terrain.

The above precautions are not limited to new tractors only, but are a good practice for tractors regardless of their age.

CHANGING LUBRICATING OIL FOR NEW TRACTORS


Special attention should be given to new tractors lubrication oil. New parts are not accustomed to each other and are not broken in properly. Small metal grit can develop in the lubricating system as metal parts begin to “break in”, and continuous use of the contaminated oil can cause damage and failure.

Therefore you should change the tractor’s oil before you normally would.

For further details of the oil change and service schedule, see “maintenance” section.

OPERATING ROPS

TO FOLD THE ROPS




- (1) Bolt
(2) Nut

1. Remove the nut and bolt.

⚠ CAUTION

- You should always stop the engine, remove the key and set the parking brake before raising or folding the rops.
- Always perform such tasks from a safe and stable position at the rear of the tractor.
- Folding the ROPS should only be done when absolutely necessary, and should be returned to the up-right position as soon as possible.




- (1) ROPS

2. Fold the **ROPS**.

⚠ CAUTION

- To avoid personal injury:
- Hold the ROPS tightly with both hands and fold the ROPS slowly and carefully.




- (1) Bolt
(2) Nut

3. Align bolt holes, insert both bolt, and secure them with the nut.

⚠ CAUTION

- To avoid personal injury:
- Make sure the bolt are properly installed and secured.

TO RAISE THE ROPS TO UPRIGHT POSITION




- (1) Bolt
- (2) Nut

1. Remove both the nut and bolt.
2. Raise **ROPS** to the upright position.

⚠ CAUTION

To avoid personal injury:

- The ROPS must be raised slowly and carefully.



- (1) Bolt
- (2) Nut

3. Align bolt holes, insert both bolt and secure them with the nut.


⚠ CAUTION

To avoid personal injury:

- Make sure that both bolt and nut are properly installed.

STARTING

ADJUSTING THE OPERATOR'S POSITION



(1) Seat (A) "PULL OUT"
(2) Position Adjust Lever


TRAVEL ADJUSTMENT

Pull out the position adjust lever and slide the seat backward or forward, as required. The seat will lock in position when the lever is released.

⊕ IMPORTANT

- After adjusting the operator's seat, be sure to check that the seat is properly locked.

SEAT BELT



(1) Seat Belt

OPERATOR'S SEAT

⚠ CAUTION

To avoid personal injury:

- Make sure that the seat is completely secured after each adjustment.

Do not allow any person other than the driver to ride on the tractor.


⚠ CAUTION

To avoid personal injury:


- Always use your seat belt when the ROPS is installed.
- Do not use the seat belt if your tractor is not equipped with a ROPS or when it is removed.

Adjust the seat belt for proper fit and connect to the buckle. The seat belt is auto-locking retractable type.

SELECTING LIGHT SWITCH POSITIONS



- (1) Turn Signal Light Switch
- (2) Head Light Switch
- (3) Hazard Light Switch
- (4) Hazard / Turn Signal Indicator



- (1) Head Light Switch
- (2) Turn Signal Light Switch
- (A) "OFF"
- (B) "ON (LOW)"
- (C) "ON (HIGH)"

HEAD LIGHT SWITCH

- (A): Head lights OFF.
- (B): Head lights - Low Beam ON.
- (C): Head lights - High Beam ON.

HAZARD LIGHT SWITCH

When hazard light switch is pulled up backward, the hazard lights flash along with the indicator on the instrument panel. Push the switch down forward to turn off the light.


TURN SIGNAL LIGHT SWITCH

To indicate a right turn, push down forward.
To indicate a left turn, push down backward.
When the left or right turn signal is activated in combination without the hazard lights, the indicated turning light will flash and the other will be off.

NOTE

- Be sure to return switch to center position after turning.


CHECKING THE BRAKE PEDAL



(1) Brake Pedal Lock

(A) Lock

(B) RELEASE



(1) Brake Pedal Lock

(A) Lock

(B) RELEASE

BRAKE PEDAL (RIGHT AND LEFT)

⚠ WARNING

To avoid personal injury:

- *Applying one rear wheel brake at a time can cause the tractor to swerve or roll over at high speeds.*


1. Before operating the tractor on the road or before applying the parking brake, be sure to interlock the right and left pedals as illustrated below.

2. Use individual brakes to assist in making sharp turns at slow speeds (Field Operation Only).

Disengage the brake pedal lock and depress only one brake pedal.


3. Be sure brake pedals have equal adjustment when using locked together.

RAISE THE IMPLEMENT (SEE
“HYDRAULIC UNIT” SECTION)



(1) Position Control Lever
(A) UP

DEPRESS THE CLUTCH PEDAL



(1) Clutch Pedal

+ IMPORTANT

To help prevent premature clutch wear.

- The clutch pedal must be engaged slowly and disengaged quickly.
- Do not rest your foot on the clutch pedal.
- Select the proper gear and engine speeds according to the type of job you are doing.


! CAUTION

To avoid personal injury:

- Do not release the clutch suddenly, it may cause the tractor to lunge forward unexpectedly.

The clutch is disengaged when the clutch pedal is fully pressed down.

SELECTING THE TRAVEL SPEED.



- (1) Main Gear Shift Lever
- (2) Range Gear Shift Lever (Hi-Lo)
- (N) NEUTRAL POSITION
- HI - HIGH
- LO - LOW

MAIN GEAR SHIFT LEVER

The main shift uses a syncro-mesh and a constant mesh.

Rotary power which is transmitted from engine to gear shaft via the clutch is changed in three ways by operating the main shift lever to shift the shifters, and transmits to the counter shaft.

RANGE GEAR SHIFT LEVER (HI-LO)

The range gear shift can only be shifted when tractor is completely stopped and clutch is depressed.


If it is difficult to shift the range gear, take the following actions.

1. Be sure the range gear shift lever is in neutral position.
2. Release clutch pedal.
3. Slightly depress the speed control pedal to rotate the gears inside of transmission.
4. Release the speed control pedal to neutral.
5. Depress clutch pedal and then shift the range gear shift lever.




IMPORTANT

- **To avoid transmission damage, depress clutch pedal and stop tractor before shifting between ranges.**



- (1) *Speed Control Pedal*
- (2) *Range Gear Shift Lever (Hi-Lo)*
- (A) *FORWARD*
- (B) *REVERSE*
- (N) *NEUTRAL POSITION*
- HI - HIGH*
- LO - LOW*


FRONT WHEEL DRIVE LEVER



(1) Front Wheel Drive Lever



ON



OFF

CAUTION

To avoid personal injury:

- You should not engage your front wheel drive while traveling at road speeds. This can cause your tractor to stop quickly, and unexpectedly.

The front wheel drive should always be engaged when the tractor is stopped. Shift the lever to the “ON” position to engage the front wheel.


IMPORTANT

- Depress the clutch pedal before engaging the front wheel drive lever.
- Tires will wear quickly if front wheel drive is engaged on paved roads.

FRONT WHEEL DRIVE IS EFFECTIVE FOR THE FOLLOWING JOBS:

1. When greater pulling force is needed, such as working in a wet field, when pulling a trailer or when working with a front-end loader.
2. When working in sandy soil.
3. When working on a hard soil where a rotary tiller might push the tractor forward.

ACCELERATE THE ENGINE



(1) Hand Throttle Lever (2) Foot Throttle



INCREASE



DECREASE


HAND THROTTLE LEVER

Pushing the throttle lever back increases engine speed, and pulling it forward decreases engine speed.

FOOT THROTTLE

Use the foot throttle when traveling on the road. Press down on it for higher speed. The foot throttle is interlocked with the hand throttle lever; when using the foot throttle, keep the hand throttle lever in low idling position.

UNLOCK THE PARKING BRAKE




(1) Brake Pedals

PARKING BRAKE LEVER

To release the parking brake, simply depress the brake pedals again. Once released, the parking brake indicator in the easy checker will go off.

DEPRESS THE SPEED CONTROL PEDAL (HST TYPE)



(1) Speed Control Pedal
(A) FORWARD (B) REVERSE

SPEED CONTROL PEDAL

⚠ WARNING

To avoid personal injury:

- *If your tractor moves while on level ground with your foot of the control pedal, do not operate the tractor.*
- *Consult your KIOTI dealer.*

FORWARD PEDAL

Depress the control pedal with the toe of your right foot to move forward.

REVERSE PEDAL

Depress the pedal with the heel of your right foot to move backward.

⊕ IMPORTANT


- **To prevent serious damage to the HST do not adjust the stopper bolts.**

LIVE P.T.O(CK20H)

“Live” P.T.O operation can be obtained with HST transmission tractor. Depress clutch and move P.T.O gear shift lever to “ON” position. Release the clutch and the P.T.O will be engaged. Forward or Reverse movement can now be obtained with the speed control pedal. To stop the tractor movement without disengaging P.T.O, step out the foot from speed control pedal and set parking brake.

The P.T.O continues running even if you change the traveling speed or stop the tractor.

Before dismounting tractor, shift the range gear shift lever (Hi-Lo) to the neutral position and set parking brake.



- (1) *Speed Set Lever*
 (2) *Speed Control Pedal*
 (A) *ON* (C) *Increase*
 (B) *OFF* (D) *Decrease*

SPEED SET DEVICE

The Speed Set Device is designed for tractor operating efficiency and operator comfort. This device will provide a constant forward operating speed by mechanically holding the speed control pedal at the selected position.

To Engage Speed Set Device

1. Accelerate speed to desired level using Speed Control Pedal, and push the speed set lever down to the “ON” position.
2. Release Speed Control Pedal and desired speed will be maintained.

To Disengage Speed Set Device

1. Place the lever to the off position.

STOPPING**NOTE**

- If you step on the pedal on the forward travel side, the speed set device will disengage.
- Make sure to keep the speed set lever in the off position when starting the tractor.
- Return the speed set lever to the off position when stopping the tractor.
- Speed set device will not operate in reverse.
- The speed control lever can be released when overloads or any sudden forces are obtained.


⊕ IMPORTANT

- To prevent the damage of speed set device, do not depress the reverse travel side pedal when the speed set device is engaged.

⚠ CAUTION

- To avoid personal injury and maintain optimum control of tractor, do not use the speed set device at high speeds or when roading the tractor.

1. Slow the engine to an idle
2. Depress the clutch and brake pedal
3. After the tractor has stopped, disengage the P.T.O, lower the implement, shift the transmission into neutral, release the clutch pedal and set the parking brake.


HORN(only EU)

(1) Horn Switch

(2) Horn

CHECK DURING DRIVING

IMMEDIATELY STOP THE ENGINE IF



(1) Easy Checker
(2) Fuel Gauge

(3) Coolant Temperature Gauge


- The engine suddenly slows or accelerates.
- Unusual noises are heard.
- Exhaust fumes become dark.

While driving make the previous checks to ensure that all parts are functioning properly.

EASY CHECKER

If warning lamps come on while operating the engine, immediately stop the engine and check for the cause.


Never operate the tractor while warning lamps are on.



ENGINE OIL PRESSURE INDICATOR

When the oil pressure in the tractor's engine falls below the prescribed level, the warning lamp will illuminate.

If this should happen during tractor operation and it does not go off when the engine is accelerated above 1,000 rpm, check the engine oil level.



ELECTRICAL CHARGE INDICATOR


If the alternator is not charging the battery, the warning lamp in the Easy Checker will come on.

If this should happen during operation, check the electrical charging system or consult your local **KIOTI** dealer.

NOTE

- For checking and servicing of your tractor, consult your local **KIOTI** dealer for instructions.

FUEL GAUGE




(1) Fuel Gauge
(A) EMPTY (B) FULL

When the key switch is on, the fuel gauge indicates the fuel level.

Be careful not to empty the fuel tank. Otherwise air may enter the fuel system.

Should this happen, the system should be bled (See "Bleeding Fuel System" in as required in Periodic Service Section.)

COOLANT TEMPERATURE GAUGE



(1) Coolant Temperature Gauge
(A) COOL (B) HOT


CAUTION

To avoid personal injury:

- **Do not remove radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any pressure before removing cap completely.**


1. When the key switch is turned "ON" this gauge indicates the temperature of the coolant. "C" is for cold, and "H" is for hot.

HOURMETER / TACHOMETER



(1) Tachometer (2) Hour meter
(A) P.T.O: 540 rpm

1. The tachometer indicates the engine speed and the 540rpm P.T.O shaft speed location on the dial.
2. The hour-mater indicates, in five digits, the hours that the tractor has been operated.
3. Records the hour and portions of the hours that the tractor has been operated based on an average speed of 2200RPM. Engine speeds below 2200RPM accumulate engine hours at a slower rate than clock hours. Engine speeds above 2200RPM accumulate engine hours faster than clock hours.

PARKING**PARKING BRAKE LEVER**

(1) Parking Brake Lever
 (A) Interlock the Brake Pedals
 (B) DEPRESS (C) PULL

⚠ CAUTION

To avoid personal injury:

- Always set the parking brake and stop the engine before leaving the tractor seat.

1. When parking, be sure to set the parking brake.


To set the parking brake;

- 1) Interlock the brake pedals.
- 2) Depress the brake pedals.
- 3) latch the brake pedals with the parking brake lever.

⊕ IMPORTANT

- To prevent damage to the parking brake lever, make sure that brake pedals are fully depressed before pulling the parking brake lever up.

2. Before getting off the tractor, disengage the P.T.O, lower all implements, place all control levers in their neutral positions, set the parking brake, stop the engine and remove the key.
3. If it is necessary to park on an incline, be sure to chock the wheels to prevent accidental rolling of the machine.

HANDBRAKE(only EU-CK20)

(1) Handbrake
 (2) Push button


A conventional handbrake lever(1) is installed to the right of the driver's seat.

To apply the handbrake, pull the lever up. To release, ease the lever up further, depress the button(2) on the end lower the lever fully.

⊕ IMPORTANT

- Ensure that the handbrake is fully released before driving off.

SEAT(only EU)



(1) Seat
 (2) Suspension Assembly(XH2)
 (3) Horizontal adjustment(Slide rails)

(4) Height adjuster
 (5) Weight adjuster

The seat installed on your tractor has a comprehensive range of adjustments. Before prorating the tractor, it is important to adjust the seat to the comfortable position.


- 1.The lever which control the seat position (up or down) in accordance with operator's. Use the lever when you change the seat position.
2. When you change the seat position (front or rear), pull the lever up and push or pull seat to front or rear direction.
3. When you change the suspension of the seat, you can adjust the suspension of the seat using the lever. Pull the lever front direction and move the lever left or right.

! CAUTION

- For one seated occupant.
- Do not adjust seat when vehicle is in operation.
- Keep clear of maintenance should be carried out by authorized & competent personnel only.

OPERATING TECHNIQUES

DIFFERENTIAL LOCK



- (1) Differential Lock Pedal
 (A) Press to "ENGAGE"
 (B) Release to "DISENGAGE"

⚠ WARNING

To avoid personal injury due to loss of steering control.


- Do not operate the tractor at high speeds with the differential lock engaged.
- Do not attempt to turn with the differential lock engaged.

If one of the rear wheels should slip you should use the differential lock. This will cause both wheels to turn together. The differential lock is engaged only when the pedal is depressed.

⊕ IMPORTANT

- When using the differential lock, always slow the engine down.
- To prevent damage to power train, do not engage differential lock when one wheel is spinning and the other is completely stopped.
- If the differential lock cannot be released in the above manner, step lightly on the brake pedals alternately.

OPERATING THE TRACTOR ON A ROAD



- (1) SMV

 **CAUTION**

To avoid personal injury:

- **To help assure straight line stops when driving at transport speeds, lock the brake pedals together. Uneven braking at road speeds could cause the tractor to roll-over.**
- **When traveling on road with 3-point hitch mounted implement attached, be sure to have sufficient front weight on the tractor to maintain steering ability.**

You should make sure that the warning lamps and SMV sign are clean and visible at all times. If you are towing rear mounted equipment or implements you will need to install the warning lamps and SMV sign on the equipment.

OPERATING ON A SLOPES AND ROUGH TERRAIN

 **CAUTION**

To avoid personal injury:

- **Always back up when going up a steep slope. Driving forward could cause the tractor to tip over backward. Stay off hills and slopes too steep for safe operation.**
- **Avoid changing gears when climbing or descending a slope.**
- **If operating on a slope, never disengage the clutch or shift levers to neutral. Doing so could cause loss of control.**
- **Do not drive the tractor close to the edges of ditches or banks which may collapse under the weight of the tractor. Especially when the ground is loose or wet.**


1. Be sure that the wheels are adjusted to provide the maximum stability possible.
2. You should slow down for rough roads, slopes, and sharp turns. This is especially important when you are transporting heavy equipment on the rear of the tractor.
3. You should use gears according to the decent of the slope, and try to avoid using the brake.

DIRECTIONS FOR USE OF POWER STEERING

1. Power steering is activated only while the engine is running. Slow engine speeds make the steering a little heavier. While the engine is stopped, the tractor functions in the same manner as tractors without power steering.
2. When the steering wheel is turned all the way to the stop, the relief valve is activated. Do not hold the steering wheel in this position for a long period of time.
3. Avoid turning the steering wheel while the tractor is stopped, or tires may wear out sooner.
4. The power steering mechanism makes the steering easier. Be careful when driving on an road at high speeds.

P.T.O OPERATION

P.T.O GEAR SHIFT LEVER



1960731A

(1) P.T.O Gear Shift Lever

☼ OFF

☼ ON

⚠ CAUTION

To avoid personal injury:

- Disengage P.T.O, stop engine, and allow all rotating components to come to a complete stop before connecting, disconnecting, adjusting, or cleaning any P.T.O driven equipment.

1. The tractor has a 540 rpm speed position.
2. P.T.O shifting needs clutch operation. Press the clutch pedal down completely to stop the tractor movement and any P.T.O driven equipment movement before shifting the P.T.O gear shift lever.

⊕ IMPORTANT


- To avoid shock loads to the P.T.O, reduce engine speed when engaging the P.T.O, then open the throttle to the recommended speed:
- To avoid damage of transmission, before shifting the P.T.O gear shift lever, fully disengage the main clutch.

Model	Engine Speed min-1 (rpm)	Shaft	P.T.O Speed min-1 (rpm)
CK20 CK20H	2,646	6-Spline	540

NOTE

- There is a P.T.O-1 (540 rpm) indicated mark on the tachometer board.
- Tractor engine will not start if P.T.O gear shift lever is in the engaged "ON" position.

P.T.O SHAFT COVER AND SHAFT CAP




1960734A

(1) P.T.O Shaft Cover (2) P.T.O Shaft Cap


You should keep the P.T.O cover in place at all times and remember to replace the cap when the P.T.O shaft is not in use.

MID-P.T.O LEVER



(1) P.T.O. Gear Shift Lever
(2) Mid-P.T.O. Lever

MID-P.T.O SHAFT COVER



(1) Mid P.T.O. (3) P.T.O. Shaft Cover
(2) Bolt

MID-P.T.O

⚠ WARNING

To avoid personal injury:

- Before operation, be sure to select the correct P.T.O lever (mid / rear).
- Do not operate rear-P.T.O driven implements and mid-P.T.O driven implements at the same time.

To use mid-P.T.O, shift the P.T.O gear shift lever and mid-P.T.O lever to engaged position. This shifting requires clutch pedal operation.

REAR AND MID-P.T.O SPEED

P.T.O REVOLUTION [mn ⁻¹ (rpm)]		
MID-P.T.O lever	P.T.O	P.T.O Gear Sift Lever/ P.T.O Clutch control lever
		→
	Rear	0 540
	Mid	0 0
	Rear	0 540
	Mid	0 2,000


The mid P.T.O is available for **KIOTI** approved implements.

8

**THREE-POINT HITCH &
DRAWBAR**

**THREE-POINT HITCH & DRAWBAR
3-POINT HITCH
DRAWBAR**


THREE-POINT HITCH & DRAWBAR




- (1) Top Link
- (2) Lifting Rod (Left)
- (3) Turnbuckle
- (4) Lower Link
- (5) Lifting Rod (Right)
- (6) Drawbar
- (7) Fixed Drawbar Frame

3-POINT HITCH

MAKE PREPARATIONS FOR ATTACHING IMPLEMENT



ATTACHING AND DETACHING IMPLEMENTS



(1) Lifting Rod (Right) (3) Lower Linle
(2) Nut

SELECTING THE TOP LINK MOUNTING HOLES

Select the proper set of holes by referring to the "Hydraulic Control Unit Use Reference Chart" in Hydraulic Unit section.

DRAWBAR

Remove the drawbar if close mounted implement is being attached.

CAUTION

To avoid personal injury:


- Be sure to stop the engine.
- Do not stand between tractor and implement unless parking brake is applied.
- Before attaching or detaching implement, locate the tractor and implement on a firm level surface.
- Whenever an implement or other attachment is connected to the tractor 3-point hitch, check full range of operation for interference, binding or P.T.O separation.

LIFTING ROD (RIGHT)

Lift Rod - To adjust the horizontal position of the implement twist the turn buckle on the right lift rod. Most implements are designed to operate level. Set the position desired by tightening the set nut against the turn buckle.

TOP LINK

1. Adjust the angle of the implement to the desired position by shortening or lengthening the top link.
2. The proper length of the top link varies according to the type of implement being used.



(1) Turn Buckle (3) Check Chains
(2) Nut

CHECK CHAINS

Check chains are used to adjust the side sway that your implement has while in use. Check Chains are also used to center the implement on the rear of the tractor.


⚠ WARNING

- **Use caution when adjusting the check chains. Heavy implement can move causing harm.**

To adjust the check chains, loosen the set nuts and twist the turn buckles on both sides until the desired amount of sway is reached. (Refer to the table below). Set the adjustment by tightening the set nuts against the turn buckles.

DRAWBAR

ADJUSTING DRAWBAR LENGTH



(1) P.T.O Shaft (3) Drawbar Pin
(2) Drawbar (A) Holes

⚠ WARNING

To avoid personal injury:

- **Never pull from the top link, the rear axle or any point above the drawbar. Doing so could cause the tractor to tip over rearward causing personal injury or death.**


The drawbar load is referred to “IMPLEMENT LIMITATIONS” section.

9 HYDRAULIC UNIT

3-POINT HITCH CONTROL SYSTEM
AUXILIARY HYDRAULICS

3-POINT HITCH CONTROL SYSTEM

HYDRAULIC CONTROL




(1) Hydraulic Control Lever
 (A) DOWN (N) NEUTRAL
 (B) UP

Operating the hydraulic control lever actuates the hydraulic lift arm. This controls the elevation of the 3-point hitch mounted implement.

⊕ IMPORTANT

- If the 3-point hitch can not be raised by setting the hydraulic control lever to the “UP” position after long term storage or when changing the transmission oil, follow these air bleeding procedures.
 1. Stop the engine.
 2. Set the hydraulic control lever to the “DOWN” position and start the engine.
 3. Operate the engine at low idle speed for at least 30 seconds to bleed air from the system.
- Do not operate until the engine is warmed up. If operation is attempted when the engine is still cold, the hydraulic system may be damaged.
- If noises are heard when implement is lifting after the hydraulic control lever has been activated, the hydraulic mechanism is not adjusted properly. Unless corrected the unit will be damaged. Contact your KIOTI dealer for adjustment.

IMPLEMENT LOWERING LIMIT




(1) Hydraulic Control Lever
(2) Lock Bolt

The implement lowering limit can be changed and adjusted by shifting the locker.

LOWER LIMIT

The lower limit can be adjusted by moving the position of the locker. Shifting the locker backward raises the lower limit and shifting the locker forward lowers the lower limit.

3-POINT HITCH LOWERING SPEED



(1) 3-Point Lowering Speed Knob
(A) FAST (C) LOCK
(B) SLOW

⚠ CAUTION

To avoid personal injury:

- Fast lowering speed may cause damage or injury. Lowering speed of implement should be adjusted to two or more seconds.

The lowering speed of the 3-point hitch can be controlled by adjusting the 3-point lowering speed knob.

HYDRAULIC BLOCK TYPE OUTLET

Hydraulic block type outlet is useful when adding hydraulically operated equipment such as:


front end loader, front blade, etc.

WHEN IMPLEMENT IS ATTACHED


1. Remove the plugs.
2. Route the implement inlet, outlet, and return hoses as shown in the illustration.
3. Move the control screw groove to “vertical position” when implement is attached.

⊕ IMPORTANT

- To prevent overheating and damage to the hydraulic system once an implement is detached, be sure the control screw is turned back to the “Horizontal position”.



- (1) To Hydraulic Control Valve (3-point hitch)
- (2) To Power steering (PS type only)
- (3) From Gear Pump
- (4) To Gear Pump (Relief Valve)
- (5) From Implement
- (6) To Implement




- (1) Flow Priority Valve
 - (2) Inlet from Implements (PS 3/8")
 - (3) Outlet to Implements (PS 3/8")
 - (4) Directional Valve
 - (5) Pin (Setting Position for Attaching Implements)
 - (6) Pin (Setting Position for Attaching no Implement)
 - (7) Relief Valve
- (A) Out (B) In

The main components of the hydraulic block outlet are shown in the figure. The hydraulic block outlet is used to take power out from the tractor to operate the implements that require hydraulic pressure.

AUXILIARY HYDRAULICS

JOYSTICK VALVE




- (T) To the Tank
 (P) From the Pump
 (A1) A1 Port
 (A2) A2 Port
 (B1) B1 Port
 (B2) B2 Port

- Boom Cylinder : A1,B1
- Bucket Cylinder : A2,B2

NOTE

- When the lever is at each corner position marked by*, boom and bucket cylinders work at the same time. However, the position marked by cross is not recommended for scooping because of insufficient lift force.



To begin test operation, slightly move the control lever from the "N" position. Slowly raise the loader boom just enough for the bucket to clear the ground when fully dumped. Slowly work through the dump and roll back cycles.

⊕ IMPORTANT

- If the boom or bucket does not work in the directions indicated in the label, lower the bucket to the ground, stop the engine, and relieve all hydraulic pressure. Re-check and correct all hydraulic connections.

REMOVE VALVE TYPE

This loader control valve has two stage dump position. The first dump position by moving the lever to the right is the "Regular" dump position.

It has good power and control for dumping precisely. This position should be used when operating another implement with the loader's control valve.

The second dump position (to further right) features greater speed for dumping. These two position are separated by a "Feel" position for your convenience.

⊕ IMPORTANT

- Do not move the control lever into float position when the bucket is off the ground.

REMOTE CONTROL VALVE COUPLER CONNECTING AND DISCONNECTING

CAUTION

To avoid personal injury:

- Stop the engine and relieve pressure before connecting or disconnecting lines.
- Do not use your hand to check for leaks.

CONNECTING

1. Clean both couplers.
2. Remove dust plugs.
3. Insert the implement coupler to the tractor hydraulic coupler.
4. Pull the implement coupler slightly to make sure couplers are firmly connected.


DISCONNECTING

1. Lower the implement first to the ground to release hydraulic pressure in the hoses.
2. Clean the couplers.
3. Relieve pressure by moving hydraulic control levers with engine shut off. Pull the hose straight from the hydraulic coupler to release it.
4. Clean oil and dust from the coupler, then replace the dust plugs.

NOTE

- Your local **KIOTI** Dealer can supply parts to adapt couplers to hydraulic hoses.

REMOTE CONTROL VALVE LEVER



(1) Remote Control Valve Lever
 (A) A Port (C) Push
 (B) B Port (D) Pull

Pressure →
 Returning ←

Lever (1)		Push	Pull
Port	A	In ←	Out →
	B	Out →	In ←

	Coupler Size
Port A, B	PT 1/2"






Move the lever up or down and hold. This will raise or lower the implement. Lever will return to neutral when released.

⊕ IMPORTANT

- Do not hold the lever in the “pull” or “push” position once the remote cylinder has reached the end of the stroke, as this will cause oil to flow through the relief valve. Forcing oil through the relief valve for extended periods will overheat the oil.
- When using the tractor hydraulic system to power front loader, do not operate boom and bucket cylinders simultaneously.

HYDRAULIC CONTROL UNIT USE REFERENCE CHART

In order to handle the hydraulics properly, the operator must be familiar with the following. Though this information may not be applicable to all types of implements and soil conditions, it is useful for general conditions.

Implement	Soil condition	with draft control		Gauge wheel	Turn buckle	Remarks
		Top link mounting holes	Position control lever			
	 196O909A	 196O910A	 196O911A	 196O912A	 196O913A	
Moldboard plow	Light soil Medium soil Heavy soil	1 or 2 2 or 3 3	Position control	-	Loose	Adjust the Turn buckle so that the implement can move 5 to 6 cm (2.0 to 2.4 in.) laterally. Turn buckle should be tight enough to prevent excessive implement movement when implement is in raised position.
Disc plow	-	2 or 3				
Harrow (spike, spring tooth, disc type)	-	2 or 3		YES/NO		
Webber, rider...				-	Tighten	-
Earthmover, Digger, scraper, manure fork, rear carrier....	-	-		YES/NO		With implements with gauge wheels, lower the position control lever all the way.
Mower (mid-and rear-mount type) Hayrake, tedder....				-		-

10 TIRES, WHEELS AND BALLAST

TIRES
TREAD
BALLAST
TRAVELING SPEED

TIRES

WARNING

To avoid personal injury:

- **Do not attempt to mount a tire. This should be done by a qualified person with the proper equipment.**
- **Always maintain the correct tire pressure. Do not inflate tires above the recommended pressure shown in the operator's manual.**

IMPORTANT

- **Do not use tires larger than specified.**
- **When you intend to mound different size of tires from equipped ones, consult your dealer about front drive gear ratio for details. Excessive wear of tires may occur due to improper gear ratio.**

INFLATION PRESSURE

Though the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it everyday and inflate as necessary.

	Tire sizes	Inflation Pressure
Rear	9.5 - 16, 6PR	207 kPa (2.1 kgf/cm ² , 30 psi)
	33 x 12.5 - 16.5, 4PR	207 kPa (2.1 kgf/cm ² , 30 psi)
	12 - 16.5, 6PR	276 kPa (2.8 kgf/cm ² , 40 psi)
Front	6 - 12, 4PR	193 kPa (2.0 kgf/cm ² , 28 psi)
	23 x 8.50 - 12, 4PR	152 kPa (1.5 kgf/cm ² , 22 psi)
	23 x 8.50 - 12, 6PR	241 kPa (2.5 kgf/cm ² , 35 psi)

NOTE

- Maintain the maximum pressure in front tires, if using a front loader or when equipped with a full load of front weights.


TREAD

FRONT WHEELS

Front tread can not be adjusted.

⊕ IMPORTANT
<ul style="list-style-type: none"> ● Do not turn front discs to obtain wider tread.

NOTE
<ul style="list-style-type: none"> ● IND... for Industrial



(A) Tread



Models	CK 20, CK20H		
Tires	6 - 12 Farm	23x8.50-12 Turf	23x8.50-12 IND
Tread	909 mm (35.8 in.)	1,014 mm (39.9 in.)	1,014 mm (39.9 in.)

REAR WHEELS


Rear wheel tread width can be adjusted as shown with the standard equipment tires.

To change the tread width.

1. Remove the wheel rim and the disk mounting bolts.
2. Change the position of the rim and disk to the desired position, and then tighten the bolts.

Models	 A	 A
CK20, CK20H 9.5 - 16 Farm	890 mm (35 in.)	935 mm (36.8 in.)
CK20, CK20H 33x12.5-16.5Turf	-	995 mm (39.2 in.)
CK20, CK20H 12 - 16.5 IND	-	1,015 mm (40 in.)

A: Tread




(1) 215 N·m (22 kgf·m, 160 lbs·ft)

⊕ IMPORTANT
<ul style="list-style-type: none"> ● Always attach tires as shown in the drawings. ● If not attached as illustrated, transmission parts may be damaged. ● When re-fitting or adjusting a wheel, tighten the bolts to the following torques then recheck after driving the tractor 200 m (200 yards) and thereafter according to service interval. (See "MAINTENANCE" section)

BALLAST (OPTIONAL)

FRONT BALLAST



(1) Front End Weights
(2) Rear Wheel Weights

⚠ CAUTION

To avoid personal injury:

- Additional ballast will be needed for transporting heavy implements. When the implement is raised, drive slowly over rough ground, regardless of how much ballast is used.
- Do not fill the front wheel with liquid to maintain steering control.

FRONT END WEIGHTS

Front end weights can be attached to the front of the tractor's bumper. You should consult your implement owner's manual for the required amount of weight or contact your local **KIOTI** dealer for a recommendation.

⊕ IMPORTANT

- Never overload the tires.
- Do not add more weight than is necessary, or is indicated in chart.

Maximum weight	17 kg X 3 Pieces (112 lbs.)
----------------	--------------------------------

REAR BALLAST

Weight should be added to the rear wheels only if it is needed to improve traction or stability. The amount of weight should directly correspond to the job at hand and should be removed when not needed.

The weight should be added to the tractor in the form of liquid ballast, rear wheel weights or both.

REAR WHEEL WEIGHTS

The rear wheel weights can be attached to the rear wheel. See your implement owner's manual for the proper amount of weight or consult your local **KIOTI** dealer.

⊕ IMPORTANT

- Do not overload tires.
- Add no more weight than indicated in chart.

Maximum weight per wheel	20 kg X 2 Pieces (88.2 lbs.)
--------------------------	---------------------------------

TRAVELING SPEED

* AT RATED ENGINE RPM WITH STANDARD TIRES.

CK20

km/h(mile/h)

HI - LOW	Main		Speed
LOW	Forward	1	1.10 (0.680)
		2	1.70 (1.056)
		3	3.50 (2.170)
	Reverse		1.36 (0.845)
HIGH	Forward	1	5.11 (3.175)
		2	7.88 (4.896)
		3	16.24 (10.091)
	Reverse		6.31 (3.920)

CK20H

km/h(mile/h)

HI - LOW	Main	Speed
LOW	Forward	0 ~ 5.80 (0 ~ 3.604)
	Reverse	0 ~ 3.62 (0 ~ 2.249)
HIGH	Forward	0 ~ 14.17 (0 ~ 8.805)
	Reverse	0 ~ 9.37 (0 ~ 5.822)

11 MAINTENANCE

SERVICE INTERVALS
LUBRICANTS

SERVICE INTERVALS

No.	Period		Indication on hour meter																Since then	Reference page
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800		
1	Engine oil	Change	⊙	○		○		○		○		○		○		○		○	Every 100 Hr	12-10
2	Engine oil filter	Replace	⊙			○				○				○				○	Every 200 Hr	12-18
3	Hydraulic oil filter	Replace	⊙			○				○				○				○	Every 200 Hr	12-18,19
4	Transmission oil filter (HST)	Replace	⊙			○				○				○				○	Every 200 Hr	12-18,19
5	Transmission fluid	Change	⊙							○								○	Every 400 Hr	12-22
6	Front axle case oil	Change	⊙							○								○	Every 400 Hr	12-23
7	Greasing	-	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	12-8
8	Wheel bolt torque	Check	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	○	Every 50 Hr	12-9
9	Battery condition	Check		○		○		○		○		○		○		○		○	Every 100 Hr	12-15
10	Air cleaner element	Clean		○		○		○		○		○		○		○		○	Every 100 Hr	12-10,11
11	Fuel filter element	Clean		○		○		○		○		○		○		○		○	Every 100 Hr	12-12
		Replace								○									Every 400 Hr	12-23
12	Fan belt	Adjust		○		○		○		○		○		○		○		○	Every 100 Hr	12-17
13	Clutch	Adjust	⊙	○		○		○		○		○		○		○		○	Every 100 Hr	12-13
14	Brake(Hand brake inclusion)	Adjust		○		○		○		○		○		○		○		○	Every 100 Hr	12-13
15	Radiator hose and clamp	Check				○				○				○				○	Every 200 Hr	12-20
		Replace																	Every 2 years	12-26
16	Power steering oil line	Check				○				○				○				○	Every 200 Hr	12-20
		Replace																	Every 200 Hr	12-26
17	Fuel line	Check		○		○		○		○		○		○		○		○	Every 100 Hr	12-12
		Replace																	Every 2 years	12-26

No.	Period		Indication on hour meter																Since then	Reference page
			50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800		
18	HST oil line (HST)	Check				⊙				⊙				⊙				⊙	Every 200 Hr	12-18,19
		Replace																	Every 200 Hr	12-26
19	Toe-in	Adjust				⊙				⊙				⊙				⊙	Every 200 Hr	12-21
20	Engine valve clearance	Adjust																⊙	Every 800 Hr**	12-24
21	Cooling system	Flush																	Every 2 years	12-25
22	Coolant	Change																	Every 2 years	12-25
23	Fuel system	Bleed																	Service as required	12-27
24	Clutch housing water	Drain																12-27		
25	Fuse	Replace																12-28		
26	Light bulb	Replace																12-29		

⊕ IMPORTANT

● The jobs indicated by ⊙ must be done after the first 50 hours of operation.

LUBRICANTS

No.	Locations	Capacities		Lubricants	
		CK20HST	CK20		
1	Fuel	20ℓ (5.28 U.S.gal.)		No.2-D diesel fuel No.1-D diesel fuel if temperature is below -10°C (14°F)	
2	Coolant	5.7ℓ (1.50 U.S.gal.)		Fresh clean water with anti-freeze	
3	Engine crankcase	2.6ℓ (0.69 U.S.gal.)		Engine oil: API Service Classification CC or CD	
				Above 25°C (77°F)	SAE30, SAE10W-30 or 10W-40
				0 to 25°C (32 to 77°F)	SAE20, SAE10W-30 or 10W-40
				Below 0°C (32°F)	SAE10W, SAE10W-30 or 10W-40
4	Transmission case	18.5ℓ (4.89 U.S.gal.)	21.6ℓ (5.71 U.S.gal.)	Multi-grade transmission fluid the fluid listed below or equivalent are recommended.	
				Maker	Brand(Standard)
				Shell	DONAX-TD,DONAX-TM
				Mobil	Mobile Fluid 350
				Exxon	Torque Fluid 56
5	Front axle case (4WD only)	3.1ℓ (0.82 U.S.gal.)		SAE 90 gear oil	
6	Greasing	No. of greasing points		Capacity	Type of grease
	Battery terminal	2		Moderate amount	Multipurpose type grease

12 PERIODIC SERVICE

HOW TO OPEN THE HOOD

DAILY CHECK

EVERY 50 HOURS

EVERY 100 HOURS

EVERY 200 HOURS

EVERY 400 HOURS

EVERY 600 HOURS

EVERY 800 HOURS


EVERY 1 YEAR

EVERY 2 YEAR


SERVICE AS REQUIRED

HOW TO OPEN THE HOOD

HOOD




(1) Knob (A) PULL
(2) Hood



(1) Hood Rod

ENGINE COVER



(1) Sider Cover (A) Push

⚠ CAUTION

To avoid personal injury from contact with moving parts:

- Never open the hood or engine side cover while the engine is running.
- Do not touch muffler or exhaust pipes while they are hot; severe burns could result.

To open the tractors hood you should first pull the knob to release the latch.

To remove the sider cover.

It is not necessary to remove the side cover to do daily check on your tractor.

DAILY CHECK

For your own safety and maximum service life of the machine, make a thorough daily inspection before operating the machine to start the engine.

⚠ CAUTION


To avoid personal injury:

- Be sure to check and service the tractor on a flat place with the engine shut off and the parking brake "ON".

WALK AROUND INSPECTION

Look around and under the tractor for such items as loose bolts, trash build-up, oil or coolant leaks, broken or worn parts.

CHECKING ENGINE OIL LEVEL



(1) Oil Inlet

(2) Dipstick

(A) Oil Level is Acceptable Within This Range.

⚠ CAUTION

To avoid personal injury:

- Be sure to stop the engine before checking the oil level.


1. Park the machine on a flat surface.
2. Check engine oil before starting the engine or 5 minutes or more after the engine has stopped.
3. To check the oil level, draw out the dipstick, wipe it clean, replace it, and draw it out again. Check to see that the oil level lies between the two notches. If the level is too low, add new oil to the prescribed level at the oil inlet.

(See "LUBRICANTS" in Maintenance Section)

⊕ IMPORTANT

- When using an oil of different maker or viscosity from the previous one, remove all of the old oil. Never mix two different types of oil.
- If oil level is low, do not run engine.


CHECKING TRANSMISSION FLUID LEVEL



1. Park the machine on a flat surface, lower the implement and shut off engine.
 2. View the fluid level through the fluid level gauge. If the level is too low, add new oil to the prescribed level at the oil inlet.
- (See "LUBRICANTS" in Maintenance Section)


⊕ IMPORTANT

- If oil level is low, do not run engine.



- (1) Oil Filling Plug
 (2) Gauge
 (A) Oil Level is Acceptable Within This Range.

CHECKING AND REFUELING



(1) Fuel Tank Cap

Fuel tank capacity	20 ^l (5.28 U.S.gal.)
--------------------	------------------------------------

⚠ CAUTION

- To avoid personal injury:
- Do not smoke while refueling.
 - Be sure to stop the engine before refueling.

1. Turn the key switch to "ON", check the amount of fuel by fuel gauge.
2. Fill fuel tank when fuel gauge shows 1/4 or less fuel in tank.
3. Use grade No.2-Diesel fuel at temperatures above -10°C (14°F).


Flash Point, °C (°F)	Water and Sediment, volume %	Carbon Residue on, 10 percent Residuuum, %	Ash, weight %
Min	Max	Max	Max
52 (125)	0.05	0.35	0.01

⊕ IMPORTANT
<ul style="list-style-type: none"> ● Do not permit dirt or trash to get into the fuel system. ● Be careful not to let the fuel tank become empty, otherwise air will enter the fuel system, necessitating bleeding before next engine start. ● Be careful not to spill during refueling. If should spill, wipe it off at once, or it may cause a fire. ● To prevent condensation (water) accumulation in the fuel tank, fill the tank before parking overnight.

Distillation Temperatures, °C(°F) 90% Point		Viscosity Kinematic cSt or mm ² /s at 40°C		Viscosity Saybolt, SUS at 100°F		sulfur, weight %	Copper Strip Corrosion	Cetane Number
Min	Max	Min	Max	Min	Max	Max	Max	Min
282 (540)	338 (640)	1.9	4.1	32.6	40.1	0.50	No.3	40

NOTE
<ul style="list-style-type: none"> ● No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87) ● Grade of Diesel Fuel Oil According to ASTM D975

CHECKING COOLANT LEVEL



(1) Recovery Tank

(A) FULL

(B) LOW

CAUTION

To avoid personal injury:

- Do not remove radiator cap while coolant is hot. When cool, slowly rotate cap to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely.

1. Check to see that the coolant level is between the “FULL” and “LOW” marks of recovery tank.
2. When the coolant level drops due to evaporation, add water only up to the full level.

In case of leakage, add anti-freeze and water in the specified mixing ratio up to the full level.

(See “Flush Cooling System and Changing Coolant” in every 2 years maintenance.)

IMPORTANT

- If the radiator cap has to be removed, follow the caution above and securely retighten the cap.
- Use clean, fresh water and anti-freeze to fill the recovery tank.
- If water should leak, consult your local KIOTI dealer.


CHECKING BRAKE AND CLUTCH PEDALS

1. The brake and clutch pedals should be inspected for free travel, and smooth operation.
2. You should adjust these pedals if an incorrect measurement is found. (See “adjusting clutch and brake pedals” in the 100 hour maintenance schedule.)


NOTE

- Brake pedals should be equal when depressed.

CLEANING GRILL, RADIATOR SCREEN AND OIL COOLER SCREEN



(1) Radiator Screen (A) DETACH



(2) Oil Cooler Screen

⚠ CAUTION

To avoid personal injury:

- Be sure to stop the engine before removing the screen.

1. Check front grill and side screens to be sure they are clean of debris.
2. Detach the screen and remove all the foreign material.

⊕ IMPORTANT

- Grill and screen must be clean from debris to prevent engine from overheating and to allow good air intake for the air cleaner.

CHECKING GAUGES, METER AND EASY CHECKER

1. Inspect the instrument panel for broken gauge(s), meter(s) and Easy Checker lamps.
2. Replace if broken.

CHECKING HEAD LIGHT, HAZARD LIGHT ETC.

1. Inspect the lights for broken bulbs and lenses.
2. Replace if broken.


CHECKING SEAT BELT AND ROPS

1. Always check condition of seat belt and **ROPS** attaching hardware before operating tractor.
2. Replace if damaged.


EVERY 50 HOURS**LUBRICATING GREASE FITTINGS**

You should apply a small amount of multi-purpose grease to the following pints every 50 hours or as needed.


If your tractor is operated in extremely wet, muddy, or dusty conditions you should lubricate the fittings more often.




(1) Grease Fitting (Power steering cylinder)
(RH, LH)
(2) Grease Fitting (Front bracket)




(1) Grease Fitting (Power steering cylinder)
(RH, LH)




(1) Grease Fitting (Brake Lever RH, LH)



(1) Grease fitting (Rear bracket)




(1) Grease Fitting (Top Link)



(1) Battery (2) Battery Terminals

CHECKING WHEEL BOLT TORQUE



(1) Bolt : 83 N·m (8.5 kgf·m, 62 lbf·ft)
 Nut : 68 N·m (7 kgf·m, 50 lbf·ft)
 (2) Bolt, Nut : 215 N·m (22 kgf·m, 160 lbf·ft)


⚠ CAUTION

To avoid personal injury:


- Never operate tractor with a loose rim, wheel, or axle.
- Any time bolts and nuts are loosened, retighten to specified torque.
- Check all bolts and nuts frequently and keep them tight.

Check wheel bolts and nuts regularly especially when new. If they are loose, tighten them as follows.

EVERY 100 HOURS CHANGING ENGINE OIL




(1) Oil Inlet (2) Dipstick
(A) Oil level is acceptable within this range



(1) Drain Plug

CLEANING AIR CLEANER PRIMARY ELEMENT



(1) Element (3) Evacuator Valve
(2) Cover

CAUTION

To avoid personal injury:

- Be sure to stop the engine before changing the oil.
- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. To drain the used oil, remove the drain plug at the bottom of the engine and drain the oil completely into the oil pan. All the used oil can be drained out easily when the engine is still warm.
2. After draining reinstall the drain plug.
3. Fill with the new oil up to the upper notch on the dipstick.

Oil capacity with filter	CK20H	2.6 ℓ (0.69U.S.gal.)
	CK20	

1. Remove the air cleaner cover and element.
2. Clean the element:
 - 1) When dry dust adheres to the element, blow compressed air from the inside, turning the element. Pressure of compressed air must be under 686kPa (7 kgf/cm³, 99 psi).
 - 2) When carbon or oil adheres to the element, soak the element in detergent for 15 minutes then wash it several times in water, rinse with clean water and dry it naturally. After element is fully dried, inspect inside of the element with a light and check if it is damaged or not.
3. Replace air cleaner element:

Once yearly or after every sixth cleaning, whichever comes first.

NOTE

- Check to see if the evacuator valve is blocked with dust.


⊕ IMPORTANT

- **The air cleaner uses a dry element, never apply oil.**
- **Do not run the engine with filter element removed.**
- **Be sure to refit the cover with the arrow ↑ (on the rear of cover) upright. If the cover is improperly fitted, evacuator valve will not function and dust will adhere to the element.**
(See “Replacing Air Cleaner Secondary Element” in Every 1 Year maintenance.)

EVACUATOR VALVE

Open the evacuator valve once a week under ordinary conditions - or daily when used in a dusty place - to get rid of large particles of dust and dirt.

CLEANING FUEL FILTER



- (1) Fuel Cock
 (2) Fuel Filter Bowl
 (3) O-Ring
 (4) Filter Element
 (5) Spring
 (6) Filter Bowl
 (7) Screw Ring
 (A) Close


+ IMPORTANT

- If dust and dirt enters the fuel system, the fuel pump and injection nozzles are subject to premature wear. To prevent this, be sure to clean the fuel filter bowl and element periodically.

This job can be done in the field but in a clean place.

1. Close the fuel cock.
2. Unscrew the ring and remove the filter bowl. Rinse the inside with kerosene.
3. Take the filter element out and dip it in the kerosene to clean.
4. After cleaning you should reassemble the filter element, making sure that it is free from dust and dirt.
5. Bleed the fuel system. (See "Bleeding the fuel System" in the service section)

CHECKING FUEL LINE




- (1) Fuel Lines (2) Clamp Bands

1. Check to see that all lines and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace or repair them at once.

NOTE

- If the fuel line is removed, be sure to properly bleed the fuel system. (See "Bleeding Fuel System" in as required maintenance)

ADJUSTING CLUTCH PEDAL




(1) Clutch Rod (A) Free Travel
(2) Nut

Proper clutch pedal free travel (A)	20 ~ 30 mm (0.8 ~ 1.2 in.) on the pedal
-------------------------------------	---

1. Stop the engine and remove the key.
2. Slightly depress the clutch pedal and measure free travel at top of pedal stroke.
3. If adjustment is needed, loosen the lock nut, remove the clevis pin and adjust the rod length within acceptable limits.
4. Retighten the lock nut and split the cotter pin.

ADJUSTING BRAKE PEDAL



(1) Lock Nut (2) Brake Rod
(A) Free Travel


⚠ CAUTION
To avoid personal injury: ● Stop the engine and chock the wheels before checking brake pedal.

Proper brake pedal free travel (A)	20 ~ 30 mm (0.787 ~ 0.181 in.) on the pedal.
	Keep the free travel in the right and left brake pedals equal.

1. Release parking brake
2. Slightly depress the pedals and measure the free travel at the top of the pedal stroke.
3. When adjustments are needed, loosen the locking nut and turn the turnbuckle until the rod length is at the desired and acceptable limit.
4. Re-tighten the lock nuts.

ADJUSTING HANDBRAKE

(only EU-CK20)



1. Please adjust the parking brake wire by following the assembling dimensions as shown.

(A) : 19 mm (B) : 17 mm

(C) : 15 mm

(D) : End play Adjustment

(E) : End play Adjustment


2. Please be careful not to bend the parking brake wire for assembling it.
3. Please fasten the nut securely not to be loosen the parking brake wire.
4. Please assemble the ball of wire to keep on moving freely.

⚠ CAUTION

The adjustment of the parking brake wire should be followed by adjusting the end play of the brake pedal.

- (1) Parking Brake Wire
 (2) Parking Brake Bracket
 (3) Parking Brake Bracket 1
 (4) Parking Brake Wire 1
 (5) Parking Brake Wire 3

BATTERY



(1) Battery

(2) Vent Cap

Mishandling or abuse of the battery can shorten the service life and adds to maintenance cost of the tractor.

If the battery is weak it will cause the engine to be hard to start and also make lights dim. It is important to check the battery periodically.

⚠ CAUTION

To avoid personal injury:


- Never remove the vent caps while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are splattered with it, wash it away completely with water immediately and get medical attention.
- Wear eye protection and rubber gloves when working around the battery.

BATTERY CHARGING

⚠ CAUTION

To avoid personal injury:

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
- When charging the battery, ensure the vent caps are securely in place. (If equipped)
- When disconnecting the cable from the battery, start with the negative terminal first.
- When connecting the cable to the battery, start with the positive terminal first.
- Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.



(A) Highest Level

(B) Lowest Level

1. Make sure each electrolyte level is somewhere between the markings (A) and (B). Add a proper amount of distilled water up to the highest level as required.
2. The water in the electrolyte evaporates during recharging. Liquid shortage damages the battery. Excessive liquid spills over and damages the tractor body.

3. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then recharge in the standard fashion.

4. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time.

When using a boost-charged battery, it is necessary to recharge the battery as early as possible.

Failure to do this will shorten the battery's service life.

5. When the specific gravity of electrolyte is between 1.27 and 1.29 the charging is completed.
6. When exchanging an old battery for a new one, use battery of equal specification shown in table 1.

Table 1


Tractor model	Battery TYPE	Volts (v)
CK20H CK20	535MF(USA) Delkor DF65D(EU)	12

DIRECTION FOR STORAGE

1. When storing the tractor for a long period, remove the battery from tractor, adjust the electrolyte to the proper level and store in a dry place out of direct sunlight.
2. The battery self-discharges while it is stored.

Recharge it once every three months in hot seasons and once every six months in cold seasons.

ADJUSTING FAN BELT TENSION



- (1) Bolt
 (A) Check the Belt Tension
 (B) To Tighten


⚠ CAUTION

To avoid personal injury:
 ● Be sure to stop the engine before checking belt tension.

Proper fan belt tension

A deflection of between 7 ~ 9 mm (0.28 ~ 0.34 in.) when the belt is pressed in the middle of the span.

1. Stop the engine and remove the key.
2. Apply moderate thumb pressure to belt between pulleys.
3. If tension is incorrect, loosen the alternator mounting bolts and, using a lever placed between the alternator and the engine block, pull the alternator out until the deflection of the belts falls within acceptable limits.
4. Replace fan belt if it is damaged.

EVERY 200 HOURS**REPLACING ENGINE OIL FILTER**

(1) Engine Oil Filter

⊕ IMPORTANT

- To prevent serious damage to the engine, use only a KIOTI genuine filter.

⚠ CAUTION


To avoid personal injury:

- Be sure to stop the engine before changing oil filter cartridge.
- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. Remove the oil filter.
2. Put a film of clean engine oil on the rubber seal of the new filter.
3. Tighten the filter quickly until it contacts the mounting surface.

Tighten filter by hand an additional half turn only.

4. After the new filter has been replaced, the engine oil normally decreases a little. Make sure that the engine oil does not leak through the seal and be sure to check the oil level on the dipstick. Then, replenish the engine oil up to the prescribed level.

REPLACING HYDRAULIC OIL & TRANSMISSION OIL FILTER (CK20H)


(1) Drain Plugs

⚠ CAUTION


To avoid personal injury:

- Be sure to stop the engine before changing the oil filter cartridge.
- Allow engine to cool down sufficiently, oil can be hot and can burn.



1. Remove the drain plug at the bottom of the transmission case and drain the oil completely into the oil pan.
2. After draining reinstall the drain plug.



(1) Hydraulic Oil Filter



(1) HST Oil Filter



(1) Gauge

(2) Oil Filling Plug

(A) Oil level is Acceptable Within this Range.


3. Remove the oil filter.
4. Place a film of clean transmission fluid of the rubber seal of the new filter.
5. Tighten the filter firmly until it contacts the mounting surface. Then tighten the filter, by hand, an additional half turn only.

6. After the new filter is in place , fill the transmission up with oil to the upper line of the oil guage.
7. After running the engine for a few minutes, stop it and check the oil level again, add oil to the prescribed level.
8. Make sure that the transmission fluid doesn't leak through the seal.

⊕ IMPORTANT

- To prevent serious damage to the hydraulic system, use only a KIOTI genuine filter.

CHECKING RADIATOR HOSE AND CLAMP



- (1) Radiator Hoses
(2) Clamp

Check to ensure the radiator hoses are free from damage and are tightened properly every 200 hours or every 6 months, whichever comes first.

1. If the hose clamps are loose or water leaks from hose, tighten clamps securely.
2. If the radiator hoses are swollen, hardened, cracked, or otherwise damaged, you must replace the hose.


It is a good practice to replace the radiator hoses once every two years.

PRECAUTION AT OVERHEATING

Take the following actions in the event the coolant temperature be nearly or more than the boiling point, what is called "Overheating"

1. Stop the machine operation in a safe place and keep the engine unloaded idling.
2. Don't stop the engine suddenly, but stop it after about 5 minutes of unloaded idling.
3. Keep yourself well away from the machine for further 10 minutes or while the steam blown out.
4. Checking that there is no danger of burn, get rid of the causes of overheating according to the manual, see "Troubleshooting" section, and then, start the engine again.


CHECKING HST OIL LINE (CK20H) & POWER STEERING LINE




- (1) HST Oil Line
(2) Power Steering Line

1. Check to see that all hydraulic lines and hose clamps are tight and undamaged.
2. If damage is found you should replace the hose or clamp at once.

ADJUSTING TOE-IN



(A) Wheel - to - wheel distance at rear
(B) Wheel - to - wheel distance at front





(1) Tie Rod (2) Lock Nuts


ADJUSTING PROCEDURE

1. Park tractor on a flat place.
 2. Turn steering wheel so front wheels are in the straight ahead position.
 3. Lower the implement, lock the park brake and stop the engine.
 4. Measure distance between tire beads at front of tire, hub height.
 5. Measure distance between tire beads at rear of tire, hub height.
 6. Front distance should be 2 ~ 8 mm less than rear distance. If not, adjust tie rod length.
1. Loosen the lock nut and turn the turn-buckle to adjust the rod length until the proper toe-in measurement is obtained.
 2. Retighten the lock nut.

EVERY 400 HOURS



(1) Drain Plugs



(1) Gauge (2) Oil Filling Plug
(A) Oil level is acceptable within this range

CHANGING TRANSMISSION FLUID

⚠ CAUTION

To avoid personal injury:

- Allow engine to cool down sufficiently, oil can be hot and can burn.

1. To drain the used oil, remove the drain plug at the bottom of the transmission case and drain the oil completely into the oil pan.
2. After draining reinstall the drain plug.
3. Fill with the new **KIOTI TF65** fluid up to the upper line of the gauge.

(See "LUBRICANTS" in Maintenance Section)

4. After running the engine for a few minutes, stop it and check the oil level again; add oil to prescribed level.

⊕ IMPORTANT


- Do not operate the tractor immediately after changing the transmission fluid. Run the engine at medium speed for a few minutes to prevent damage to the transmission.

Oil Capacity	CK20H	18.5 ℓ (4.89 U.S.gal.)
	CK20	21.6 ℓ (5.71 U.S.gal.)

REPLACING FUEL FILTER ELEMENT

(See "Cleaning fuel filter" in every 100 hours maintenance.)

CHANGING FRONT AXLE CASE OIL



(1) Check Plug
(3) Drain Plug


(2) Filling Plug

1. To drain the used oil, remove the right and left drain plugs and filling plug at the front axle case and drain the oil completely into the oil pan.
2. After draining reinstall the drain plugs.
3. Remove the oil level check plug.
4. Fill with the new oil up to the check plug port.
(See "LUBRICANTS" in Maintenance Section)
5. After filling reinstall the filling plug and check plug.

Oil Capacity	3.1 ℓ (0.82 U.S.gal.)
--------------	--------------------------

EVERY 600 HOURS

ADJUSTING FRONT AXLE PIVOT



(1) Adjusting Screw (2) Lock Nut

If the front axle pivot pin adjustment is not correct, front wheel vibration can occur causing vibration in the steering wheel.

ADJUSTING PROCEDURE

Loosen the lock nut, tighten the adjusting screw all the way, and then loosen the screw by 1/6 turn. Retighten the lock nut.

EVERY 800 HOURS

ADJUSTING ENGINE VALVE CLEARANCE

Consult your local **KIOTI** dealer for this service.


EVERY 1 YEAR

REPLACING AIR CLEANER ELEMENT


(See "Cleaning Air Cleaner Element" in every 100 hours maintenance.)

EVERY 2 YEARS

FLUSH COOLING SYSTEM AND CHANGING COOLANT



(1) Drain Plug



(1) Radiator Cap (A) FULL
(2) Recovery Tank (B) LOW

⊕ IMPORTANT

- Do not start engine without coolant.
- Use clean, fresh water and anti-freeze to fill the radiator and recovery tank.
- When the anti-freeze is mixed with water, the anti-freeze mixing ratio must be less than 50%.
- Securely tighten radiator cap. If the cap is loose or improperly fitted, water may leak out and the engine could overheat.

⚠ CAUTION

- To avoid personal injury:**
- Do not remove the radiator cap when the engine is hot. Then loosen cap slightly to stop the relieve any excess pressure before removing cap completely.

1. Stop the engine and let cool down.
2. To drain the coolant, open the radiator drain plug and remove radiator cap. The radiator cap must be removed to completely drain the coolant.
3. After all coolant is drained, close the drain plug.
4. Fill with clean water and cooling system cleaner.
5. Follow directions of the cleaner instruction.
6. After flushing, fill with clean water and anti-freeze until the coolant level is just below the port.
Install the radiator cap securely.
7. Fill with coolant up to the "FULL" mark on the recovery tank.
8. Start and operate the engine for few minutes.
9. Stop the engine and let cool.
10. Check coolant level of recovery tank and add coolant if necessary.

Coolant capacity	CK20H CK20	5.7 l (1.50 U.S.gal.)
------------------	---------------	--------------------------

ANTI-FREEZE

If cooling water freezes, it can damage the cylinders and radiator. It is necessary, if the ambient temperature falls below 0°C (32°F), to remove cooling water after operating or to add anti-freeze to it.

1. There are two types of anti-freeze available; use the permanent type (PT) for this engine.
2. Before adding anti-freeze for the first time, clean the radiator interior by pouring fresh water and draining it a few times.
3. The procedure for mixing of water and anti-freeze differs according to the make of the anti-freeze and the ambient temperature, basically it should be referred to SAE J1034 standard, more specifically also to SAE J814C.
4. Mix the anti-freeze with water, and then fill into the radiator.

Vol % Anti-freeze	Freezing Point		Boiling Point*	
	°C	°F	°C	°F
40	-24	-12	106	222
50	-37	-34	108	226

- * At 760 mmHg pressure (atmospheric). A higher boiling point is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.

NOTE

- The above data represents industry standards that necessitate a minimum glycol content in the concentrated anti-freeze.
- When the cooling water level drops due to evaporation, add water only. In case of leakage, add anti-freeze and water in the specified mixing ratio.
- Anti-freeze absorbs moisture. Keep unused anti-freeze in a tightly sealed container.
- Do not use radiator cleaning agents when anti-freeze has been added to the cooling water. (Anti-freeze contains an anti-corrosive agent, which will react with the radiator cleaning agent forming sludge which will affect the engine parts.)

REPLACING RADIATOR HOSE (WATER PIPES)

Replace the hoses and clamps.
(See “Checking Radiator Hose and Clamp” in every 200 hours maintenance.)

REPLACING POWER STEERING HOSE

Replace the hoses and clamps.
(See “Checking power steering line” in every 200 hours maintenance.)

REPLACING HST OIL LINE


Replace the hoses and clamps.
(See “Checking HST oil line” in every 200 hours maintenance.)

REPLACING FUEL HOSE

Replace the hoses and clamps.
(See “Checking Fuel line” in every 100 hours maintenance.)

SERVICE AS REQUIRED

BLEEDING FUEL SYSTEM



(1) Fuel Cock

(A) Close

(B) Open

Air must be removed:

1. When the fuel filter or lines are removed.
2. When tank is completely empty.
3. After the tractor has not been used for a long period of time.

BLEEDING PROCEDURE IS AS FOLLOWS:


1. Fill the fuel tank with fuel, and open the fuel cock.
2. Open the air vent cock on the fuel injection pump.
3. Start the engine and run for about 30 seconds, and then stop the engine.
4. Close the air vent cock.



IMPORTANT

- **Always close the air vent cock except for bleeding fuel lines. Otherwise, engine runs irregularly or stalls frequently.**

DRAINING CLUTCH HOUSING WATER




(1) Split Pin Plugs


Your tractor is equipped with a split pin plug under the clutch housing.

After you operate your tractor in the rain, snow, or after washing the tractor, water may get into the clutch housing. If this happens, remove the plug in the clutch housing and drain water. Remember to reinstall the plug to avoid serious damage to clutch.

REPLACING FUSE



(1) Fuse Box



20A	15A	10A	20A		
PREHEAT CONT. TIMER RELAY	CUST- OMER USE	WORK LIGHT	HEAD LAMP/ TAIL LAMP	SPARE	SPARE
SPARE FUSE		10A	20A	25A	
		10A	15A	20A	FUSE HOLDER
SPARE	SPARE	STOP LAMP	TIMER RELAY	TURN SIG- NAL LAMP HORN	
PART NO.		T2350-69901			
USE ONLY THE RATING CAPACITY FUSE.					

196OC52A


The tractor electrical system is protected from potential damage by fuses.

A blown fuse indicates that there is an overload or short somewhere in the electrical system.

If any of the fuses should blow, replace with a new one of the same capacity.

⊕ IMPORTANT

- Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the tractor electrical system. Refer to the troubleshooting section of this manual or your local KIOTI dealer for specific information dealing with electrical problems.



(1) Slow Blow Fuse

PROTECTED CIRCUIT

No.	Capacity (A)	Protected circuit
1	20	Flasher / Horn
2	10	Work Light
3	15	Head Lights / Tail Light
4	15	Timmer Relay
5	10	Stop Lights
6	15	Customer Use

REPLACING LIGHT BULB

1. Head lights and rear combination lights:
Take the bulb out of the light body and replace with a new one.
2. Other lights:
Detach the lens and replace the bulb.

	Light	Capacity
1	Head Lights(USA)	23W / 35W
2	Head Lights(EU)	55W / 60W
3	Head Lights(EN)	40W / 45W
4	Tail Lights(USA)	21W
5	Stop Lights(USA)	21W
6	Front Position Lamps(EU)	5W
7	Stop Lights/Rear Position(EU)	21W / 5W
8	Turn signal Lights(EU)	21W
9	Work Light	21W
10	Instrument panel Light	3.4W

13 STORAGE

TRACTOR STORAGE
REMOVING THE TRACTOR FROM STORAGE

TRACTOR STORAGE


CAUTION

To avoid personal injury:

- Do not clean the machine with engine running.
- To avoid the danger of exhaust fume poisoning, do not operate the engine in a closed building without proper ventilation.
- When storing, remove the key from the key switch to avoid unauthorized persons from operating the tractor and getting injured.

If you intend to store your tractor for an extended period of time, follow the procedures outlined below. These procedures will insure that the tractor is ready to operate with minimum preparation when it is removed from storage.

1. Check the bolts and nuts for looseness, and tighten if necessary.
2. Apply grease to tractor areas where bare metal will rust also to pivot areas.
3. Detach the weights from the tractor body.
4. Inflate the tires to a pressure a little higher than usual.
5. Change the engine oil and run the engine to circulate oil throughout the engine block and internal moving parts for about five minutes.
6. Pull the engine stop knob all the way out.
7. Keep the clutch disengaged. If the clutch is left engaged for a long period of time, the clutch plate may rust, making clutch disengagement impossible at the next operation.



- (1) Clutch Pedal (A) Depress
(2) Latch (B) Hook to Lock

8. With all implements lowered to the ground, coat any exposed hydraulic cylinder piston rods with grease.
9. Remove the battery from the tractor. Store the battery following the battery storage procedures. (See "Battery condition" in every 50 hours in periodic service section.)

REMOVING THE TRACTOR FROM STORAGE

10. Keep the tractor in a dry place where the tractor is sheltered from rain. Cover the tractor.

11. Store the tractor indoors in a dry area that is protected from sunlight and excessive heat. If the tractor must be stored outdoors, cover it with a waterproof tarpaulin.

Jack the tractor up and place blocks under the front and rear axles so that all four tires are off the ground. Keep the tires out of direct sunlight and extreme heat.

IMPORTANT

- **When washing the tractor, be sure to stop the engine. Allow sufficient time for the engine to cool before washing.**
- **Cover the tractor after the muffler and the engine have cooled down.**

1. Check the tire air pressure and inflate the tires if they are low.
2. Jack the tractor up and remove the support blocks from under the front and rear axles.
3. Install the battery. Before installing the battery, be sure it is fully charged.
4. Check the fan belt tension.
5. Check all fluid levels (engine oil, transmission/hydraulic oil, engine coolant and any attached implements.)
6. Start the engine. Observe all gauges. If all gauges are functioning properly and reading normal, move the tractor outside. Once outside, park the tractor and let the engine idle for at least five minutes. Shut the engine off and walk around tractor and make a visual inspection looking for evidence of oil or water leaks.
7. With the engine fully warmed up, release the parking brake and test the brakes for proper adjustment as you move forward. Adjust the brakes as necessary.

14 TROUBLESHOOTING

ENGINE TROUBLESHOOTING

ENGINE TROUBLESHOOTING

If something is wrong with the engine, refer to the table below for the cause and its corrective measure.

Trouble		Cause	Countermeasure
Engine is difficult to start or won't start		<ul style="list-style-type: none"> No fuel flow. 	<ul style="list-style-type: none"> Check the fuel tank and the fuel filter. Replace filter if necessary.
		<ul style="list-style-type: none"> Air or water is in the fuel system. 	<ul style="list-style-type: none"> Check to see if the fuel line coupler bolt and nut are tight. Bleed the fuel system (See "Bleeding Fuel System" in as required maintenance)
		<ul style="list-style-type: none"> In winter, oil viscosity increases, and engine revolution is slow. 	<ul style="list-style-type: none"> Use oils of different viscosities, depending on ambient temperatures.
		<ul style="list-style-type: none"> Battery becomes weak and the engine does not turn over quick enough. 	<ul style="list-style-type: none"> Clean battery cables & terminals. Charge the battery. In cold weather, always remove the battery from the engine, charge and store it indoors. Install it on the tractor only when the tractor is going to be used.
Insufficient engine power.		<ul style="list-style-type: none"> Insufficient or dirty fuel. The air cleaner is clogged. 	<ul style="list-style-type: none"> Check the fuel system. Clean or replace the element.
Engine stops suddenly.		<ul style="list-style-type: none"> Insufficient fuel. 	<ul style="list-style-type: none"> Refuel. Bleed the fuel system if necessary.
Exhaust fumes are colored.	Black	<ul style="list-style-type: none"> Fuel quality is poor. Too much oil. The air cleaner is clogged. 	<ul style="list-style-type: none"> Change the fuel and fuel filter. Check the proper amount of oil. Clean or replace the element.
	Blue white	<ul style="list-style-type: none"> The inside of exhaust muffler is dumped with fuel. Injection nozzle trouble. Fuel quality is poor. 	<ul style="list-style-type: none"> Heat the muffler by applying load to the engine. Check the injection nozzle. Change the fuel and fuel filter. Shift to lower gear or reduce load.

Trouble	Cause	Countermeasure
Engine overheats	• Engine overloaded	• Shift to lower gear or reduce load.
	• Low coolant level	• Fill cooling system to the correct level; check radiator and hoses for loose connections or leaks.
	• Loose or defective fan belt	• Adjust or replace fan belt.
	• Dirty radiator core or grille screens	• Remove all trash.
	• Coolant flow route corroded	• Flush cooling system.

If you have any questions, contact your local **KIOTI** dealer.

15 OPTIONS

OPTIONS



OPTIONS

Consult your local **KIOTI** dealer for further detail.

- SMV (Slow Moving Vehicle) Emblem
To identify slow moving vehicle
- Work Light
High visibility for night work
- Drawbar
- Front end weights
For front ballast
- Rear Wheel Weights
For rear ballast
- Sunshade

16 INDEX

INDEX



A			
AUXILIARY HYDRAULICS	9-5	Cleaning Grill, Radiator Screen and Oil Cooler Screen	12-7
Joystick Valve	9-5	Checking gauges, Meter and Easy . Checker	12-7
Remote Control Valve Coupler Connecting and Disconnecting	9-6	Checking Head Light, Hazard Light . ETC.	12-7
Remote Control Valve Lever	9-7	Checking Seat Belt and ROPS	12-7
B		DAILY CHECK	5-2
BALLAST	10-4	Check Item	5-2
Front Ballast	10-4	DRAWBAR	8-4
Rear Ballast	10-4	Adjusting Drawbar Length	8-4
BEFORE OPERATING THE TRACTOR ..	1-2	DRIVING THE TRACTOR	1-8
C		E	
CHECK DURING DRIVING	7-16	ENGINE TROUBLESHOOTING	14-2
Immediately Stop the Engine If	7-16	EVERY 1 YEAR	12-24
Easy Checker	7-17	Replacing Air Cleaner Element ...	12-24
Fuel Gauge	7-18	EVERY 100 HOURS	12-10
Coolant Temperature Gauge	7-18	Checking Engine Oil	12-10
Hourmeter/Tachometer	7-18	Cleaning Air Cleaner Primary Element ..	12-10
D		Cleaning Fuel Filter	12-12
DAILY CHECK	12-3	Checking Fuel Line	12-12
Checking Engine Oil Level	12-3	Adjusting Clutch Pedal	12-13
Checking Transmission Fluid Level ...	12-4	Adjusting Brake Pedal	12-13
Checking and Refueling	12-4	Adjusting Handbrake	12-14
Checking Coolant Level	12-6	Battery	12-15
Checking Brake and Clutch Pedals	12-6	Adjusting Fan Belt Tension	12-17
		EVERY 2 YEAR	12-25
		Flush Cooling System and Changing Coolant	12-25
		Anti-Freeze	12-26
		Replacing Radiator Hose	12-26
		Replacing Power Steering Hose	12-26
		Replacing HST Oil Line	12-26
		Replacing Fuel Hose	12-26
		EVERY 200 HOURS	12-18
		Replacing Engine Oil Filter	12-18
		Replacing Hydraulic Oil & Transmission Oil Filter (CK20H)	12-18
		Checking Radiator Hose and Clamp	12-20
		Checking HST Oil Line(CK20H) & Power Steering Line	12-20
		Adjusting TOE-IN	12-21
		EVERY 400 HOURS	12-22
		Changing Transmission Fluid	12-22
		Replacing Fuel Filter Element	12-23
		Changing Front Axle Case Oil	12-23
		EVERY 50 HOURS	12-8
		Lubricating Grease Fittings	12-8
		Checking Wheel Bolt Torque	12-9
		EVERY 600 HOURS	12-24
		Adjusting Front Axle Pivot	12-24
		EVERY 800 HOURS	12-24
		Adjusting Engine Valve Clearance	12-24

- F**
FOOT AND HAND CONTROLS 4-3
- H**
HOW TO OPEN THE HOOD 12-2
Hood 12-2
Engine Cover 12-2
- I**
IMPLEMENT LIMITATIONS 3-4
INSTRUMENT PANEL, SWITCHES AND
HAND CONTROLS 4-2
- J**
JUMP STARTING 6-7
- L**
LUBRICANTS 11-4
- O**
OPERATING TECHNIQUES 7-21
Differential Lock 7-21
Operating the Tractor on a Road .. 7-21
Operating on a Slopes and Rough ter-
rain 7-22
Directions for Use of Power Steering .. 7-22
- OPERATING ROPS 7-3
To Fold the ROPS 7-3
To Raise the ROPS to Up Right Position
..... 7-4
Adjustment of Foldable ROPS 7-4
- OPERATING NEW TRACTOR 7-2
- OPERATING THE P.T.O 1-10
- OPERATING THE TRACTOR 1-5
- OPTIONS 15-2
- P**
P.T.O OPERATION 7-23
P.T.O Gear Shift Lever 7-23
P.T.O Shaft Cover and Shaft Cap ... 7-23
MID-P.T.O Lever 7-24
MID-P.T.O Shaft Cover 7-24
MID-P.T.O 7-24
- PARKING THE TRACTOR 1-9
- PARKING 7-19
Parking Brake Lever 7-19
Hand Brake 7-19
- R**
REMOVING THE TRACTOR FROM STOR-
AGE 13-3
- S**
SEAT 7-20
- SERVICE AS REQUIRED 12-27
Bleeding Fuel System 12-27
Draining Clutch Housing Water .. 12-27
Replacing Fuse 12-28
Replacing Light Bulb 12-29
- SERVICE INTERVALS 11-2
- SERVICING THE TRACTOR 1-11
- SERVICING 2-2
- SPECIFICATIONS 3-2
- STARTING THE ENGINE 6-2
- STARTING 7-5
Adjusting the Operator's Position .. 7-5
Seat Belt 7-5
Selecting Light Switch Position 7-6
Checking the Brake Pedal 7-7
Raise the Implement (See "HYDRAULIC
UNIT" Section) 7-8
Depress the Clutch Pedal 7-8
Selecting the Travel Speed 7-9
Front Wheel Drive Lever 7-12
Accelerate the Engine 7-12
Unlock the Parking Brake 7-13
Depress the Speed Control Pedal (HST
TYPE) 7-13

STOPPING THE ENGINE 6-6

STOPPING 7-15

T

3 - POINT HITCH 8-3

 Make Preparations for Attaching Implement 8-3

 Attaching and Detaching Implements 8-3

THREE-POINT HITCH & DRAWBAR 8-2

3 - POINT HITCH CONTROL SYSTEM .. 9-2

 Hydraulic Control 9-2

 Implement Lowering Limit 9-3

 3-Point Hitch Lowering Speed 9-3

 Hydraulic Block Type Outlet 9-3

TIRES 10-2

 Inflation Pressure 10-2

TRACTOR SAFETY LABELS 1-14

TRACTOR STORAGE 13-2

TRAVELING SPEED 10-5

TREAD 10-3

 Front Wheels 10-3

 Rear Wheels 10-3

U

USING 3-POINT HITCH 1-10

W

WARMING UP 6-6

 Warm-UP and Transmission Oil In the .
 Low Temperature Range 6-6